

Intel[®] Xeon[®] Processor with 800 MHz System Bus, Intel[®] E7520 Chipset, and Intel[®] 6300ESB ICH Development Kit

User's Manual

March 2007



INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER, AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. Intel products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or in nuclear facility applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

Intel Corporation may have patents or pending patent applications, trademarks, copyrights, or other intellectual property rights that relate to the presented subject matter. The furnishing of documents and other materials and information does not provide any license, express or implied, by estoppel or otherwise, to any such patents, trademarks, copyrights, or other intellectual property rights.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

Intel processor numbers are not a measure of performance. Processor numbers differentiate features within each processor family, not across different processor families. See http://www.intel.com/products/processor_number for details.

The Intel® Xeon™ Processor, Intel® E7520 Chipset, Intel® 6300ESB ICH Development Kit may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Hyper-Threading Technology requires a computer system with an Intel® Pentium® 4 processor supporting HT Technology and a HT Technology enabled chipset, BIOS and operating system. Performance will vary depending on the specific hardware and software you use. See http://www.intel.com/products/ht/Hyperthreading_more.htm for additional information.


Contact your local Intel sales office or your distributor to obtain the latest specifications and before placing your product order.

Copies of documents which have an order number and are referenced in this document, or other Intel literature may be obtained by calling 1-800-548-4725 or by visiting Intel's website at <http://www.intel.com>.

BunnyPeople, Celeron, Celeron Inside, Centrino, Centrino logo, Core Inside, Dialogic, FlashFile, i960, InstantIP, Intel, Intel logo, Intel386, Intel486, Intel740, IntelDX2, IntelDX4, IntelSX2, Intel Core, Intel Inside, Intel Inside logo, Intel. Leap ahead., Intel. Leap ahead. logo, Intel NetBurst, Intel NetMerge, Intel NetStructure, Intel SingleDriver, Intel SpeedStep, Intel StrataFlash, Intel Viiv, Intel vPro, Intel XScale, IPLink, Itanium, Itanium Inside, MCS, MMX, Oplus, OverDrive, PDCharm, Pentium, Pentium Inside, skool, Sound Mark, The Journey Inside, VTune, Xeon, and Xeon Inside are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

*Other names and brands may be claimed as the property of others.

Copyright © 2007, Intel Corporation. All Rights Reserved.



Contents

1.0	Product Overview	6
1.1	Related Documents	6
1.2	Product Contents	6
1.3	Products Feature List	7
1.4	Block Diagram	8
1.4.1	Memory Subsystem	10
1.4.2	DIMM Placement DDR2-400	10
1.5	Memory Population Rules and Configurations	11
2.0	Platform Management	12
2.1	Power Button	12
2.2	Soft Off	12
2.3	Sleep States Supported	12
2.3.1	S0 State	12
2.3.2	S1 State	12
2.3.3	S2 State	13
2.3.4	S3 State	13
2.3.5	S4 State	13
2.3.6	S5 State	13
2.3.7	Wake-Up Events	14
2.3.8	Wake-Up from S1 Sleep State	14
2.3.9	Wake-Up from S4 and S5 States	14
2.4	PCI PM Support	14
2.5	Platform Management	14
2.5.1	Processor Thermal Management	14
2.6	System Fan Operation	14
3.0	Equipment Required for CRB Usage	16
3.1	Precautions	16
3.2	Driver and OS Requirements	17
3.2.1	Drivers Included on CD	17
4.0	Jumpers and Headers	21
4.1	Jumpers	21
5.0	System Overview	25
5.1	Power Diagrams	25
5.2	Platform Clocking	26
5.3	Platform Resets	27
5.4	SMBus	28
5.5	Platform IRQ Routing	29
5.6	VRD VID Headers	30
5.7	Miscellaneous Buttons	32
6.0	Debug Procedure	33
6.1	Level 1 Debug (Port 80/BIOS)	33
6.2	Level 2 Debug (Power Sequence)	34
6.3	Level 3 Debug (Voltage References)	34
7.0	Heatsink Assembly	35
7.1	Processor Heat Sink Installation Instructions	36



Figures

1	Customer Reference Board Block Diagram	8
2	Placement—Top View	9
3	DDR2-400 Memory - DIMM Ordering	11
4	Intel® Xeon® Processor with 800 MHz System Bus and Intel® E7520 and Intel® 6300ESB Customer Reference Board Jumper	21
5	Power Distribution Block Diagram	25
6	Clock Block Diagram	26
7	Platform Reset Diagram.....	27
8	SMBus Block Diagram	28
9	IRQ Routing Diagram	29
10	Power Buttons.....	32
11	Components Requiring Heat Sink Assembly.....	35
12	Inserting Processor in Socket	36
13	Cleaning the Processor Surface	37
14	Installing the Processor Backplate.....	37
15	Removing the Protective Covers	38
16	Installing the Heatsink	38

Tables

1	Related Documents.....	6
2	Supported DIMM Module Types	10
3	DIMM Placement DDR2-400	10
4	Jumper Settings	22
5	Processor VRD Settings	30
6	Level 1 Debug (Port 80/BIOS)	33
7	Level 2 Debug (Power Sequence)	34
8	Level 3 Debug (Voltage References).....	34
9	Components Requiring Heat Sink Assembly.....	35



Revision History

Date	Revision	Description
March 2007	006	Updated parts list in Section 1.2 and Chapter 3.0 . Updated safety information in Section 3.1 .
January 2007	005	Added new photos to Figure 12 , Figure 13 , Figure 14 , Figure 15 and Figure 16 .
January 2005	004	Added notice of Low Voltage Intel® Xeon® processor support.
August 2004	003	Changed figures that referenced PCI-X to PCI-X 133 MHz; changed jumpers on Figure 4 ; made other miscellaneous changes.
July 2004	002	Changed code names to public names; clarified illustrations.
December 2003	001	Initial release of this document.



1.0 Product Overview

The Intel® Xeon® Processor with 800 MHz System Bus, Intel® E7520 Chipset, and Intel® 6300ESB ICH Development Kit comprise an IA-32 based dual-processor platform. This platform serves as a reference for OEMs development platform. This and other development kits from Intel provide a fully working product with range of performance options which can be modified or used immediately for product development.

1.1 Related Documents

Table 1. Related Documents


Document/Reference Title	Source/Document Number
Intel® E7520 Memory Controller Hub (MCH) Datasheet	Contact your Intel sales representative for access.
Intel® E7520 Memory Controller Hub (MCH) Specification Update	
Intel® Xeon® Processor with 800 MHz System Bus Datasheet	
Intel 6300ESB I/O Controller Datasheet	
Intel® Xeon® Processor Debug Port Design Guide	
Extended Debug Port Design Guide: for UP and DP platforms	
Schematics file	

Visit http://www.intel.com/platforms/applied/eiacomm/reference_configs.htm for the latest updates.

1.2 Product Contents

The Development Kit is shipped with the following components and features:

- Two Intel® Xeon® 3.2 GHz processors capable of 800 MT/s
- One 460 W SSI EPS12 V power supply
- Two heat sinks for the two processors
- Two pieces of DDR2-400 [1 GBytes]
- Blank hard drive
- Intel Ethernet NIC
- CD with necessary drivers
 - Red Hat* 8.0 Compatible Driver Package Contents
 - Red-Hat Advanced Server 2.1 Compatible Driver Package Contents
 - Windows* Compatible Driver Package Contents
 - ATI Rage* Mobility-M* Graphics Accelerator



1.3 Products Feature List

- Processor Support
 - Dual Intel® Xeon® processors with 800 MHz system bus (Note: The Development Kit is also drop-in compatible with Low Voltage Intel® Xeon® processors with 800 MHz system bus. These processors must be purchased separately from the Development Kit.)
 - On-board processor voltage regulators compatible with VRM/EVRD 10.1 Design Guide
- Clocking
 - CK409B clock synthesizer that generates all host clock and the PCI Express* interface clock for the MCH PHY Layer
 - DB800 generates the PCI Express differential pair clocks to the onboard PCI Express components and the dedicated PCI Express slots
- Memory Support
 - Registered, ECC, DDR2-400
 - Each of the two memory channels on the Intel® E7520 in this CRB supports a maximum of two DDR2-400 DIMMs per channel
 - The maximum supported DDR2-400 memory configuration is 8 Gbyte using different combinations of single and dual ranked, x4, 1 Gbyte technology DIMMs (limit of up to four ranks per channel)
 - 3.2 Gbytes/s bus per channel bandwidth with DDR2-400
- I/O slot support
 - One PCI-X 133 MHz slot from PXH
 - Two PCI-X 100 MHz slots from PXH
 - One PCI Express x8 slot
 - One PCI Express x4 slot
 - One 5 V PCI-32/33 slot connected through the Intel® 6300ESB I/O Controller
 - Two 3.3 V PCI-X 64/66 slots connected through the Intel® 6300ESB I/O Controller
- Low Pin Count Bus
 - National* LPC 47M172 Super I/O residing on LPC bus
 - LPC card header for debug purposes only
 - Firmware hub
- IDE ATA 100 support
 - Two ATA-100 IDE connectors supported
- S-ATA support
 - Two S-ATA connectors
- USB Support (Four Channels)
 - Two USB 2.0 connectors
 - Two USB 2.0 headers
- Back Panel I/O
 - Two RS-232 serial ports from the Intel® 6300ESB I/O Controller
 - Two PS/2 connectors for mouse and keyboard




- On-board VGA Video, ATI Rage Mobility* video controller
- Parallel port
- Dual Watchdog Timer
- Miscellaneous
 - National LM93* for fan control and temperature/voltage monitoring

Refer to [Figure 1](#) for complete detailed features of the Intel® Xeon® Processor with 800 MHz system bus and Intel® E7520 and Intel® 6300ESB Customer Reference Board (CRB).

1.4 Block Diagram

Figure 1. Customer Reference Board Block Diagram







Figure 2. Placement—Top View



B3518-03



1.4.1 Memory Subsystem

The memory subsystem is designed to support Double Data Rate2(DDR2) Synchronous Dynamic Random Access Memory (SDRAM) using the Intel(R) E7520 MCH. The MCH provides two independent DDR channels, which support DDR2-400 DIMMs. The peak bandwidth of each DDR2 branch channel is 3.2 Gbyte/s (8 bytes x 400 MT/s) with DDR2-400. The two DDR2 channels from the MCH operate in lock step; the effective overall peak bandwidth of the DDR2 memory subsystem is 6.4 Gbyte/s for DDR2-400.

Table 2 shows all DIMM technology supported by the CRB. Other DIMM types are not supported.

Table 2. Supported DIMM Module Types

Technology	Organization	SDRAM Chips/DIMM
256 Mbit	8 Mbytes x 8 x 4 banks	8
	16 Mbytes x 4 x 4 banks	16
512 Mbit	16 Mbytes x 8 x 4 banks	8
	32 Mbytes x 4 x 4 banks	16
1 Gbit	32 Mbytes x 8 x 4 banks	8
	64 Mbytes x 4 x 4 banks	16


1.4.2 DIMM Placement DDR2-400

Table 3. DIMM Placement DDR2-400

DIMM Configuration	DIMM1	DIMM2
1 Single Rank	Empty	Single Rank
1 Dual Rank	Empty	Dual Rank
2 Single Rank	Single Rank	Single Rank
1 Dual Rank, 1 Single Rank	Single Rank	Dual Rank
2 Dual Rank	Dual Rank	Dual Rank

Notes:

1. Populate DIMMs starting with the sockets farthest away from the MCH (DIMM slots A2 and B2).
2. When populating both channels, always place identical DIMMs in sockets that have the same position on channel A and channel B (i.e., DIMM A2 should be identical to DIMM B2).




1.5 Memory Population Rules and Configurations

The system supports two DDR2-400 DIMM slots for Channel A and two DDR2-400 DIMM slots for Channel B. The four slots are interleaved and placed in a row in the following order: A1, B1, A2, B2, with A1 being closest to the MCH. This design supports only registered ECC-enabled DIMMs.

When populating both channels, always place identical DIMMs in sockets that have the same position on Channel A and Channel B (i.e., DIMM A2 should be identical to DIMM B2).

In addition, single-rank DIMMs should be populated furthest when a combination of single-rank and double-rank DIMMs are used. This recommendation is based on the signal integrity requirements of the DDR2 interface.

Figure 3. DDR2-400 Memory - DIMM Ordering





2.0 Platform Management

The following sections describe how the system power management operates and how the different ACPI states are implemented. Platform management involves:

- ACPI implementation specific details
- System monitoring, control and response to thermal, voltage and intrusion events
- BIOS security

2.1 Power Button

The system power button is connected to the I/O controller component. When the button is pressed, the I/O controller receives the signal and transitions the system to the proper sleep state as determined by the operating system and software. If the power button is pressed and held for four seconds, the system powers off (S5 state). This feature is called power button override and is particularly helpful in case of system hang and system lock.

2.2 Soft Off

The I/O controller incorporates a SLP_S4 output signal which routes to the power supply. This signal has register access that allows software to deactivate the power supply. When SLP_S4 goes active, the power supply cuts main power but keeps 5 V auxiliary power rails available. 5 V auxiliary voltage is active while the power supply receives AC power.

2.3 Sleep States Supported


The I/O controller controls the system sleep states. States S0, S1, S3, S4, and S5 are supported. The platform enters sleep states in response to BIOS, operating system or user actions. Normally the operating system determines which sleep state to transition into. However, a four-second power button override event places the system immediately into S5. When transitioning into a software-invoked sleep state, the I/O controller attempts to gracefully put the system to sleep by first going into the processor C2 state.

2.3.1 S0 State

This is the normal operating state, even though there are some power savings modes in this state using processor Halt and Stop Clock (processor C1 and C2 states). S0 affords the fastest wake-up response time of any sleep state because the system remains fully powered and memory is intact.

2.3.2 S1 State

This state is entered via a processor Sleep signal from the I/O controller (processor C3 state). The system remains fully powered with memory contents intact but the processors enter their lowest power state. The operating system disables bus masters



for uniprocessor configurations while flushing and invalidating caches before entering this state in multiprocessor configurations. Wake-up latency is slightly longer in this state than in S0; however, power savings are improved from S0.

2.3.3 S2 State

This state is not supported.

2.3.4 S3 State

This state is called Suspend to RAM (STR). The system context is maintained in system DRAM, but power is shut off to non-critical circuits. Memory is retained, and refreshes continue. All clocks stop except the RTC. S3 is entered when the I/O controller asserts the SLP_S3# signal to downstream circuitry to control 1.8 V power plane switching. Power must be switched from the normal 1.8 V rail to standby 1.8 V, because the EPS-12V 550 W power supply does not directly supply a standby 1.8 V rail. The sequence to enter Suspend to RAM is as follows:

1. The OS and BIOS prepare for S3 sleep state.
2. The OS sets the appropriate sleep bits in the I/O controller.
3. The I/O controller drives STPCLK to the processors.
4. The processors respond with a Stop-Grant cycle, passed over hub interface by MCH.
5. The I/O controller indicates an S3 (STR) sleep mode to the MCH via Hub Interface A.
6. The MCH puts DDR memory into the self-refresh mode.
7. The MCH drives DDR CMDCLK differential pairs and all DDR outputs low.
8. The MCH drives a completion message via Hub Interface A to the I/O controller.
9. The I/O controller turns off all voltage rails (except Standby 5V) from the main power supply by asserting the SLP_S3_N signal.
 - When in the S3 state, only the Standby 5 V rail is available from the power supply. The board uses this standby source to generate 1.8 V standby rail to power the DIMMs.
 - The asserted SLP_S3_N signal also controls the logic to switch the DIMM power source from main 1.8 V to standby 1.8 V.

2.3.5 S4 State

This state is called Suspend to Disk. From a hardware perspective, it is equivalent to an S5 state. The operating system is responsible for saving the system context in a special partition on the hard drive. Although the system must power up and fully boot, boot time to an application is reduced because the platform is returned to the same system state as when the preceding power off occurred.

2.3.6 S5 State

This state is the normal off state whether entered through the Power Button or Soft Off. All power is shut off except for the logic required to restart. The system remains in the S5 State only while the power supply is plugged into the electrical outlet. If the power supply is unplugged, this is considered a Mechanical OFF or G3.



2.3.7 Wake-Up Events

The types of wake-up events and wake-up latencies are related to the actual power rails available to the system in a particular sleep state, as well as to the location in which the system context is stored. Regardless of the Sleep State, Wake on the Power Button is always supported except in a mechanical off situation. When in a Sleep State, the system complies with the PCI specification by supplying the optional 3.3 V standby voltage to each PCI slot as well as the PME# signal. This enables any compliant PCI card to wake up the system from supported sleep states except Mechanical Off.

Note: Wake on USB, Wake on PS/2, and Wake on LAN are not supported.

2.3.8 Wake-Up from S1 Sleep State

During S1, the system is fully powered, permitting support for PCI Express* Wake and Wake on PCI PME#.

2.3.9 Wake-Up from S4 and S5 States

The power button is used to wake from S4 and S5.

2.4 PCI PM Support

This design holds the system reset signal low when in a sleep state. The system supports the PCI PME# signal and provides 3.3 V standby to the PCI and PCI Express slots. This support allows any compliant PCI or PCI Express card to wake up the system from any sleep state except mechanical off. The user and the operating system must configure the system carefully following the PCI power management interface specification because of the limited amount of power available on 3.3 V standby.

2.5 Platform Management


The LM 93 monitors the majority of the system voltages. The VID signals from the processors are also monitored by LM 93. All voltage levels can be read via the SMBus.

2.5.1 Processor Thermal Management

Each processor monitors its own core temperature and thermally manages itself when it reaches a certain temperature. The system also uses the internal processor diode to monitor the die temperature. The diode pins are routed to the diode input pins in the LM 93. The LM 93 can be programmed to force the processor fans to full speed operation when it senses the processor core temperature exceeding a specific value. In addition, the LM 93 has an on chip thermal monitor which allows it to monitor the incoming ambient temperature. Additional processor thermal management requires the system to communicate to the processors when the VRD reaches a critical temperature. The VR thermal monitor asserts FORCEPR_N signal to the processor. The thermal monitor, an LM26, is a $\pm 3^\circ$ C precision thermostat used to sense high temperature conditions and drive a digital output active low. This circuit works as an external PROCHOT event to further protect the processor during high current/temperature conditions. This forces the processor to activate a thermal protection circuit that reduces the current consumption of the processor.

2.6 System Fan Operation

The system uses both the LM 93 and the National* 87427 Super I/O to monitor and control the fans in the system. The LM93 uses pulse width modulated (PWM) outputs that can modulate the voltage across the fans, providing a variable duty cycle to effect



a reduced DC voltage from nominal 12 VDC. The fan headers are the standard 12V, three-pin type, used in previous Servers, which support tachometer out. The LM 93 also has four tachometer inputs that it can use to monitor the fans that it is controlling. All fan tachometer data can be extracted from the controllers via the SMBus. The system fan speed control circuit does not control the power supply fan. Each PWM output has a bypass jumper that causes all fans to run at full speed and ignore the PWM control. Each processor fan has its own dedicated PWM output and tachometer input, so each fan is controlled and monitored independently, depending on the core temperature. The LM 93 is dedicated to processor fan speed control and monitor, and can be programmed with temperature limit values that allow it to speed up or idle the processor fans, depending upon the input temperature.



3.0 Equipment Required for CRB Usage

The following components are required for the Intel® Xeon® Processor with 800 MHz System Bus and Intel® E7520 and Intel® 6300ESB Customer Reference Board (CRB) usage:

- A 460 W SSI EPS 12 V power supply. The CRB is shipped with the power supply.
- At least two modules of DDR2-400 DIMM. The CRB is shipped with two 1 GBytes of DDR2 400.
- Hard drive loaded with Operating System¹
- Monitor
- PS/2 mouse and keyboard

Visually inspect the board and ensure that the MCH, Intel® 6300ESB I/O Controller, PXH, and other components did not shake loose during shipment. If the board has any loose or missing components, contact your Intel representative.

Caution: Powering up without all components installed correctly could lead to a power-up failure that could damage the board. Do not power up the board until the source of any loose component is determined and the component has been replaced on the board.

3.1 Precautions


Warning: Do not install the power supply until all other installation steps have been completed. Measures must be taken to protect the unused DC connectors of the power supply from accidental contact to objects in the work area.

Note: Review the document provided with the Development Kit titled "Important Safety and Regulatory Information". This document contains addition safety warnings and cautions that must be observed when using this development kit.

The following precautions will reduce the chances of damaging the board:

- Ensure that a 460 W SSI EPV 12 V power supply is used to power up the CRB. Refer to [Section 5.1, "Power Diagrams" on page 25](#) for details on the SSI power supply interface on the CRB.
- This platform supports DDR2-400 DIMMs; ensure that the same speed DIMM is plugged in all slots of the platform.
- Ensure that each processor has heat sinks attached before powering up the board.
- Ensure that the heat sink is attached to the MCH and PXH before powering up the board. Never attach a heat sink while the board is powered.
- Use [Table 4](#) to verify that all jumpers are in their default positions.

1. Note The hard disk provided with the development kit is not pre-loaded with any software.



3.2 Driver and OS Requirements

The required INF driver for the CRB supports the functionality of the Intel® 6300ESB I/O Controller and PXH. The INF file will be included with Red Hat* compatible drivers on the CD shipped with the kit.

The CRB supports these operating systems:

- Microsoft* Windows* XP, Windows Embedded XP, 2000 Pro, 2000 Server, 2000 Advanced Server, 2003 Standard Edition
- Red Hat Linux Advanced Server 2.1, Red Hat 8.0 on kernel 2.4.x
- Wind River* VxWorks* real-time operating system
- QNX Neutrino* real-time operating system
- Customer operating systems when applicable

3.2.1 Drivers Included on CD

3.2.1.1 Red Hat 8.0 Compatible Driver Package Contents

This operating system compatible driver package is available from:

http://downloadfinder.intel.com/scripts-df/Detail_Desc.asp?agr=Y&ProductID=1706&DwnldID=7249

Package Contents

esb_rh8.txt — release notes
sources/ac97/alsa-driver-0.9.0rc5.bz2— alsa-driver sources
sources/ac97/alsa-lib-0.9.0rc5.bz2— alsa-lib sources
sources/ac97/alsa-util-0.9.0rc5.bz2— alsa-util sources
sources/ac97/alsa-xmms-0.9.9b.tar.gz— alsa plugin for xmms
sources/ac97/xmms-mpg123-1.2.7-13.i386.rpm— mpeg plugin for xmms
sources/kernel/linux-2.4.20.tar.gz— 2.4.20 kernel sources
sources/kernel/config-2.4.20-p4-upapic-i2c-apm-nooss— UP Kernel Config File
sources/kernel/config-2.4.20-p4-upapic-i2c-acpi-nooss— UP Kernel Config File
sources/kernel/config-2.4.20-p4-smp-i2c-apm-nooss— MP Kernel Config File
sources/smbus/i2c-2.7.0.tar.gz— latest I2C-core driver sources
sources/smbus/lm_sensors-2.7.0.tar.gz— latest smbus adapter/sensor sources
sources/esbwdt/LICENSE— license for Intel WDT driver
sources/esbwdt/esbwdt-doc.txt— Linux WDT Driver release notes
sources/esbwdt/driver/esbwdt.c— Linux WDT Driver source file
sources/esbwdt/driver/esbwdt.h— Linux WDT Driver header file
sources/esbwdt/driver/Makefile— Linux WDT Driver Makefile
sources/esbwdt/demoapp/esbwdt-demo.c— WDT driver demo application
patches/COPYING— GPL-v2 license for Intel patches
patches/ac97/alsa-hr.patch— enables ESB AC97 AC in ALSA
patches/ac97/alsa-hr-ich5.patch— enables ICH5 AC97 AC in ALSA
patches/ide-sata/pci_ids-hr.patch— enables ICH5 AC97 AC in ALSA
patches/ide-sata/pci_ids-hr-ich5.patch— patches to 2.4.20 IDE driver



patches/ide-sata/piix.c-hr.patch— enables PATA & SATA storage interface support

patches/ide-sata/piix.c-hr-ich5.patch— enables PATA & SATA storage interface support

patches/ide-sata/ide_pci-hr.patch— integrated into the ESB & ICH5 Southbridges

patches/ide-sata/ide_pci-hr-ich5.patch— integrated into the ESB & ICH5 Southbridges

patches/ide-sata/pci_irq-hr.patch— integrated into the ESB & ICH5 Southbridges

patches/ide-sata/pci_irq-hr-ich5.patch— integrated into the ESB & ICH5 Southbridges

patches/lspci/pciids-112202.patch— patch to update 2.4.20 pci.ids file

patches/lspci/pciids-112202-hr.patch— patch to add ESB dev IDs to pci.ids

patches/lspci/pciids-112202-hr-ich5.patch— patch to add ICH5 dev IDs to pci.ids

patches/ioapic/irqbalance-2.4.20-MRC.patch— patch for use with P4 Hyper-Threading

patches/smbus/i2c-hr.patch— enables ESB SMBUS dev in I2C driver

patches/smbus/i2c-hr-ich5.patch— enables ICH5 SMBUS dev in I2C driver

patches/smbus/i2c-2.7.0-Makefile.patch— customizations for I2C-2.7.0 Makefile

patches/smbus/lm_sensors-2.7.0-Makefile.patch— customizations for lm_sensors Makefile

patches/smbus/readme.txt— build/install instruction for lm_sensors

binaries/binaries.tar.gz— pre-build kernel and modules

utils/ks.cfg-raid015-hd-acd— raid0, 1, & 5 enabled kickstart file

utils/ks.cfg-noraid-hda— non-RAID kickstart file

utils/debug/readme-up.txt— instructions on using UP install scripts

ks.cfg-noraid-hda-cdrom-text-interactive— interactive kickstart file

install-bin.pl— script to automate UP pkg install

blsrcs.pl— script to automate UP pkg install

readme-smp.txt— instructions on using SMP install scripts

blsmpkernel.pl— script to automate SMP kernel bld/install

blsmpdrivers.pl— script to automate SMP driver modules bld

3.2.1.2 Red Hat Advanced Server 2.1 Compatible Driver Package Contents

This operating system compatible driver package is available from:

http://downloadfinder.intel.com/scripts-df/Detail_Desc.asp?agr=Y&ProductID=1706&DwnldID=7248

Package Contents

esb_rhas.txt— release notes

sources/ac97/alsa-driver-0.9.0rc5.bz2— alsa-driver sources

sources/ac97/alsa-lib-0.9.0rc5.bz2— alsa-lib sources


sources/ac97/alsa-util-0.9.0rc5.bz2— alsa-util sources

sources/ac97/alsa-xmms-0.9.9b.tar.gz— alsa plugin for xmms

sources/ac97/README— build/install instructions for ac97

sources/kernel/config-2.4.9-e.24-p4-smp-i2c— Optimized MP Kernel Config File

sources/kernel/config-2.4.9-e.24-p4-upapic-i2c— Optimized UP Kernel Config File



sources/kernel/install-2.4.9-e.24esb-grub.conf.patch— Patch to install UP kernel

sources/kernel/install-2.4.9-e.24esbsmp.patch— Patch to install SMP kernel

sources/kernel/rhas21-q2u-gold-iso— origin of RHAS Q2-03 updates

sources/smbus/i2c-2.7.0.tar.gz— latest i2c-core driver sources

sources/smbus/lm_sensors-2.7.0.tar.gz— latest smbus adapter/sensor sources

sources/esbwdt/LICENSE — license for Intel WDT driver

sources/esbwdt/esbwdt-doc.txt— esbwdt driver/demoapp release notes

sources/esbwdt/driver/esbwdt.c— esbwdt driver sources

sources/esbwdt/driver/esbwdt.h— esbwdt driver header file

sources/esbwdt/driver/Makefile— esbwdt driver Makefile

sources/esbwdt/demoapp/esbwdt-demo.c— esbwdt driver demo app

patches/COPYING— GPL-v2 license for Intel patches

patches/ac97/alsa-hr.patch— enables ESB AC97 AC in alsa

patches/ac97/alsa-hr-ich5.patch— enables ICH5 AC97 AC in alsa

patches/ide-sata/pci_ids-hr.patch— patches to 2.4.9-e.24 ide driver

patches/ide-sata/pci_ids-hr-ich5.patch— patches to 2.4.9-e.24 ide driver

patches/ide-sata/piix.c-hr.patch— to enable support for pata & sata storage interfaces

patches/ide-sata/piix.c-hr-ich5.patch— to enable support for pata & sata storage interfaces

patches/ide-sata/ide_pci-hr.patch— integrated into the esb6300 & ich5 southbridges

patches/ide-sata/ide_pci-hr-ich5.patch— integrated into the esb6300 & ich5 southbridges

patches/ide-sata/pci_irq-hr.patch— integrated into the esb6300 & ich5 southbridges

patches/ide-sata/pci_irq-hr-ich5.patch— integrated into the esb6300 & ich5 southbridges

patches/lspci/pci_ids-hr.patch— adds esb dev ids to 2.4.9-e.24 pci_ids

patches/lspci/pci_ids-hr-ich5.patch— adds ich5 dev ids to 2.4.9-e.24 pci_ids

patches/smbus/i2c-hr.patch— enables esb smbus dev in i2c driver

patches/smbus/i2c-hr-ich5.patch— enables ich5 smbus dev in i2c driver

patches/smbus/i2c-2.7.0-Makefile.patch— customizations for i2c-2.7.0 Makefile

patches/smbus/lm_sensors-2.7.0-Makefile.patch— customizations for lm_sensors Makefile

sources/smbus/lm_sensors-2.7.0-Module.mk.patch— patch to fix bld errs on rhas v21

patches/smbus/readme.txt — build/install instructions for smbus

utils/debug/ks.cfg-yyyy— basic kickstart file to install from ftp to hda

utils/debug/bldkernel.pl— script to build/install esb enabled UP kernel

utils/debug/bldsrcs.pl— script to build/install esb enabled UP drivers

utils/debug/readme.txt— BKM (aka EASIEST) way to install UP kernel & drivers

utils/debug/bldsmpkern.pl— script to build/install esb enabled SMP kernel

utils/debug/bldsmprdrivers.pl— script to build/install esb enabled SMP drivers

utils/debug/readme-smp.txt— BKM (aka EASIEST) way to install SMP kernel & drivers

3.2.1.3 Windows Compatible Driver Package Contents

This operating system compatible driver package is available from:



http://downloadfinder.intel.com/scripts-df/Detail_Desc.asp?agr=Y&ProductID=1706&DwnldID=7246

Package Contents

ESB_windows_ReInotes.txt— Release notes for Windows* compatible drivers
SMB.SYS— SMBus Driver
SMB.INF— Install file for SMBus driver
SMB.CAT— SMBus driver security catalog file
STAC97.SYS— AC'97 audio code driver provided by SigmaTel*
SLAoemsv1.doc— Single-user and OEM license for SigmaTel STA97 driver
WDTDRVR.SYS— Watchdog Timer driver
WDTDRVR.INF— Install file for Watchdog Timer driver
WDT_LICENSE.TXT— Generic Alpha license for Watchdog Timer components
WDTDEMO.EXE— Demo program for exercising Watchdog Timer features
Mfc42.dll— Microsoft C++ runtime library
Mfco42.dll— Microsoft C++ runtime library
Msvcrt.dll— Microsoft C++ runtime library
wtdemoAppSpec.pdf— WdtDemo App user documentation
wtdriverspec.pdf— Overview of Watchdog Timer driver
Intelwdtapi.pdf— Watchdog Timer driver interface API document
IWDTLIB.DLL— Watchdog Timer Interface Dynamic Link Library
CWESB.slx eXP— Configuration file
WESB.log— log of OS build for eXP
eXP-README.DOC— readme of eXP build
infinst_enu.exe— Intel INF update utility

3.2.1.4 Third Party Drivers

Included on the CD is software compatible with the ATI Rage* Mobility-M Graphics Accelerator 021112a-006561C-ATI.zip.



4.0 Jumpers and Headers

This section describes the platform component placement as well as configuration, test and debug features of the Intel® Xeon® Processor with 800 MHz System Bus and Intel® E7520 and Intel® 6300ESB Customer Reference Board.

4.1 Jumpers

Figure 4 depicts all jumpers on the CRB. Table 4 illustrates the settings and usage of the jumpers. Review Table 4 and Figure 4 before changing default setting of the jumpers on the CRB.

Figure 4. Intel® Xeon® Processor with 800 MHz System Bus and Intel® E7520 and Intel® 6300ESB Customer Reference Board Jumper






Table 4. Jumper Settings (Sheet 1 of 3)

Jumper Name	Ref Des	Description/Settings	Default Position		
3.3V Aux Enable	J1A1	Enables 3.3 V AUX 1-2: Enable 3.3 V AUX for wake events Open: 3.3 V Operation Only	1-2		
Enable PXH	J2G2	Enable PXH 1-2: Enable Open: Disable	1-2		
No Reboot	J2G3	Prevents the system from rebooting following a reset from Intel 6300ESB I/O Controller 1-2: No Reboot Open: Normal	Open		
Enable Super I/O Chip	J2J1	Enable on SIO 1-2: Enable Open: Disable	1-2		
5V Aux Enable	J3A1	Enables 5 V AUX 1-2: Enable 5 V VAUX for wake events Open: 3.3 V Operation Only	1-2		
CPU0 Present Override	J2H114	Override VRM disable if no CPU0 installed 1-2 Override Open : Normal	Open		
Enable Video	J4A1	Enable on Board video 1-2: Enable Open: Disable	1-2 (not populated)		
ICH WDT Output	J3J1	LED Control 1-2 : Illuminate LED CR4J1 when EDT expires	1-2		
	J3J2	Reset Control 1-2 : Reset board when WDT Expires	1-2		
ICH VSWING Header	J4G5	Access to ICH VSWING pin Do not Install Jumper	Open		
ICH VREF Header	J4G6	Access to ICH VREF pin Do not Install Jumper	Open		
PCI SMBus Header	J4H1	Access to PCI SMBus Do not install Jumper 1: PCI _SMBDAT 2. Ground 3. PCI_SMBCLK	Open		
DDR SMBus Header	J4H3	Access to DDR SMBus Do not install Jumper 1: DIMM _SMBDAT 2. Ground 3. DIMM_SMBCLK	Open		
FSB Clock Frequency Override (Host Clock Jumpers)	BSEL1: J4H4 BSEL0: J4J3	BSEL0	BSEL1	SPEED	BSEL0: 1-2 BSEL1: 1-2
		1-2	1-2	Normal	
		2-3	2-3	RSVD	
		2-3	Open	133 MHz	
		Open	Open	167 MHz	
Open	1-2	200 MHz			





Table 4. Jumper Settings (Sheet 2 of 3)

Jumper Name	Ref Des	Description/Settings	Default Position
SMI Inject	J4H5	Inject SMI Signal Do Not Install Jumper	Open
FORCEPRO inject	J4H6	Inject FORCEPRO Signal Do Not Install Jumper	Open
STPCLK Inject	J4J1	Inject STPCLK Signal Do Not Install Jumper	Open
FORCEPR1 inject	J4J2	Inject FORCEPR1 Signal Do Not Install Jumper	Open
CPU1 Present Override	J4J5	Override VRM disable if CPU1 is not present 1-2: Override Open: Normal	Open
BSEL Match Override	J4J7	Override VRM disable if BSELS do not match 1-2: Override Open: Normal	Open
CPU1 VID	J4K1	1-2: VID[5] 3-4: VID[4] 5-6: VID[3] 7-8: VID[2] 9-10: VID[1] 11-12: VID[0]	As Required
CPU1 VID Override	J4K2	Manual VID select 1-2: Manual select Open: CPU select	Open
MCH SMBus Header	J5D3	Access to MCH SMBus Do not install Jumper 1: MCH_SMBDAT 2. Ground 3. MCH_SMBCLK	Open
PLLS0	J5E112	See MCH Documentation for alternative Gear Ratios for MCH FSB/Memory	Short
Intel® 6300ESB I/O Controller Top Swap (FWH Memory Swap)	J5F1	Intel 6300ESB I/O Controller Top Swap 1-2: Top Swap Open: Normal	Open
PLLS1	J5F113	See MCH Documentation for alternative Gear Ratios for MCH FSB/Memory	Short
Intel 6300ESB I/O Controller Safe Mode	J5F3	Intel 6300ESB I/O Controller Safe Mode 1-2: Safe Mode Open: Normal Mode	Open
CMOS Clear	J5H1	Clears CMOS 1-2: Normal 2-3: Configure	1-2
Validation Only	J5H2	Validation only Do Not Install Jumper	Open
ICH SMBUS header	J5H3	Access to ICH SMBus Do not Install Jumper 1: ICH_SMBDAT 2. Ground 3. ICH_SMBCLK	Open
S3 Enable	J7F1	1-2: S3 Enable Open S3 Disable	1-2



Table 4. Jumper Settings (Sheet 3 of 3)

Jumper Name	Ref Des	Description/Settings	Default Position
CPU1 Fan Override	J7K1	1-2: Full Speed Open: LM93 Controlled	1-2
CPU0 Fan Override	J8J1	1-2: Full Speed Open: LM93 Controlled	1-2
ITP Configuration	J9 G4 J9G3	2-2: Uniprocessor 1-2: Dual Processor	1-2 1-2
CPU0 Boot Select	J9H2	1-2: Other processor support (RSVD) Open: Intel Xeon support	Open
CPU0 VID Override	J9K1	Manual VID select 1-2: Manual select Open: CPU select	Open
CPU0 VID	J9K2	1-2: VID[5] 3-4: VID[4] 5-6: VID[3] 7-8: VID[2] 9-10: VID[1] 11-12: VID[0]	As Required




5.0 System Overview

5.1 Power Diagrams

Figure 5 shows the power distribution for the CRB. Refer to the CRB schematics for details on the power distribution logic. (Contact your Intel field sales representative to obtain the schematics file.)

Figure 5. Power Distribution Block Diagram




B3522-01




5.2 Platform Clocking

The CRB uses one CK409B Clock Synthesizer to generate the host differential pair clocks and the 100 MHz differential clock to the DB800. The DB800 then generates the 100 MHz differential pair clock for the PCI Express* devices. Figure 6 shows the CRB clock configuration.

Figure 6. Clock Block Diagram




B2937-03




5.3 Platform Resets

Figure 7 depicts the reset logic for the CRB. The Intel 6300ESB I/O Controller provides most of the reset following assertion of power good and system reset. However, the glue logic within the SIO is also used to buffer reset to PXH, MCH, FWH, and IDE.

Figure 7. Platform Reset Diagram






5.5 Platform IRQ Routing

Figure 9 shows that the Intel 6300ESB I/O Controller uses these segments:

- IRQ14 and 15 for IDE segment
- SERIRQ for SIOPIXRQ segment
- PCRIRQ for the PCI-X segment
- PIRQ for the PCI 32/33 segment

A Message Signalled Interrupt (MSI) scheme is used between the MCH and PXH over the PCI Express bus. The PXH uses PAIRQ for the Channel A interface to PCI-X 64-bit/100 MHz peripherals and PBIIRQ for the Channel B interface to PCI-X 64/133. MSI and Non Maskable Interrupt (NMI) are connected from the Intel 6300ESB I/O Controller to CPU0 and CPU1. The platform also supports MSI for maskable and non-maskable interrupts.

Figure 9. IRQ Routing Diagram



B2940-02



5.6 VRD VID Headers

Provides for manual control of the processor core voltage regulator output level(s). Normally, the processor should be run at its default VID (voltage identification) value as set during manufacturing. However, in the event the user needs to set a different VID value from the default value, it can be accomplished through a jumper block found on the board. Note that these headers are not populated by default.

The CPU 0 VID header is located at J9K2. CPU 1 VID header is located at J4K1. Table 5 provides the VID settings available via the VID headers.

Table 5. Processor VRD Settings (Sheet 1 of 2)

VID5	VID4	VID3	VID2	VID1	VID0	V _{CC_MAX} (V)	VID5	VID4	VID3	VID2	VID1	VID0	V _{CC_MAX} (V)
0	0	1	0	1	0	0.8375	0	1	1	0	1	0	1.2125
1	0	1	0	0	1	0.8500	1	1	1	0	0	1	1.2250
0	0	1	0	0	1	0.8625	0	1	1	0	0	1	1.2375
1	0	1	0	0	0	0.8750	1	1	1	0	0	0	1.2500
0	0	1	0	0	0	0.8875	0	1	1	0	0	0	1.2625
1	0	0	1	1	1	0.9000	1	1	0	1	1	1	1.2750
0	0	0	1	1	1	0.9125	0	1	0	1	1	1	1.2875
1	0	0	1	1	0	0.9250	1	1	0	1	1	0	1.3000
0	0	0	1	1	0	0.9375	0	1	0	1	1	0	1.3125
1	0	0	1	0	1	0.9500	1	1	0	1	0	1	1.3250
0	0	0	1	0	1	0.9625	0	1	0	1	0	1	1.3375
1	0	0	1	0	0	0.9750	1	1	0	1	0	0	1.3500
0	0	0	1	0	0	0.9875	0	1	0	1	0	0	1.3625
1	0	0	0	1	1	1.0000	1	1	0	0	1	1	1.3750
0	0	0	0	1	1	1.0125	0	1	0	0	1	1	1.3875
1	0	0	0	1	0	1.0250	1	1	0	0	1	0	1.400
0	0	0	0	1	0	1.0375	0	1	0	0	1	0	1.4125
1	0	0	0	0	1	1.0500	1	1	0	0	0	1	1.4250
0	0	0	0	0	1	1.0625	0	1	0	0	0	1	1.4375
1	0	0	0	0	0	1.0750	1	1	0	0	0	0	1.4500
0	0	0	0	0	0	1.0875	0	1	0	0	0	0	1.4625
1	1	1	1	1	1	OFF	1	0	1	1	1	1	1.4750
0	1	1	1	1	1	OFF	0	0	1	1	1	1	1.4875
1	1	1	1	1	0	1.1000	1	0	1	1	1	0	1.5000
0	1	1	1	1	0	1.1125	0	0	1	1	1	0	1.5125



Table 5. Processor VRD Settings (Sheet 2 of 2)


1	1	1	1	0	1	1.1250		1	0	1	1	0	1	1.5250
0	1	1	1	0	1	1.1375		0	0	1	1	0	1	1.5375
1	1	1	1	0	0	1.1500		1	0	1	1	0	0	1.5500
0	1	1	1	0	0	1.1625		0	0	1	1	0	0	1.5625
1	1	1	0	1	1	1.1750		1	0	1	0	1	1	1.5750
0	1	1	0	1	1	1.1875		0	0	1	0	1	1	1.5875
1	1	1	0	1	0	1.2000		1	0	1	0	1	0	1.6000




5.7 Miscellaneous Buttons

Figure 10 below shows the location of the power buttons within the platform.

Figure 10. Power Buttons





6.0 Debug Procedure

The debug procedures in this section are used to determine baseline functionality for the Intel® Xeon® Processor with 800 MHz System Bus, Intel® E7520 Chipset, and Intel® 6300ESB ICH Development Kit. This is a cursory set of tests designed to provide a level of confidence in the platform operation.

6.1 Level 1 Debug (Port 80/BIOS)

Refer to the steps in [Table 6](#) when debugging a board that does not boot.

Table 6. Level 1 Debug (Port 80/BIOS)

Item	Test	Pass/Fail Criteria	Cause of Failure
1	Verify "SYSTEM PWRGD" LED	CR2H1: Green	Power Sequence Failure—go immediately to Level 2 debug
2	Is "PCI Reset" LED (decimal on DS1J2) illuminated?	Decimal on Port 80 display Red	PCI Reset Stuck—go to Level 3 debug
3	Verify CPURST LED is off	CR7K3: Off	CPU Reset Stuck—go to Level 3 debug
4	Verify Port 80 Posting	Port 80 LEDs are posting boot codes and stopping	System Hang—Check BIOS go to level 3 debug. Refer to AMI* BIOS documentation for details. Also refer to Schematic Page 68, Coord. D5.
5	Check BIOS revision	Latest BIOS installed	Contact your Intel Representative for the latest BIOS image.
6	Verify default Jumper settings	See default settings	Improper Jumper settings



6.2 Level 2 Debug (Power Sequence)

Check the items in Table 7 below if “SYSTEM PWRGD” is not illuminated.

Table 7. Level 2 Debug (Power Sequence)


Item	Test	Pass/Fail Criteria	Cause of Failure
1	Primary power supply voltages	Measure voltage across: <ul style="list-style-type: none"> • C3K2: 3.3 V • C3K1: -12 V • C4K3: 5 V • C4K2: 5 V • C4K5: 12 V 	External power supply failure
2	1.8 V	C9E14: 1.8 V	DDR2 power supply failure
3	1.5 V	C5C5: 1.5 V	MCH/PXH/ICH core power supply failure
4	1.8 VSBY	C9G5: 1.8 V	DDR2 standby power supply failure
5	CPU VTT power supply	C9H10: 1.2 V	CPU_VTT power supply failure
6	CPU0 VRD	L9J2: 1.2 V - 1.4 V	CPU0 VRD Failure
7	CPU1 VRD	L5J1: 1.2 V – 1.4 V	CPU1 VRD Failure
8	Verify “SYSTEM PWRGD” LED	CR2H1: Green	Power Sequence Failure

6.3 Level 3 Debug (Voltage References)

Table 8 includes the first items to look at when debugging a board that does not boot.

Table 8. Level 3 Debug (Voltage References)

Item	Test	Pass/Fail Criteria	Cause of Failure
1	MCH DDR2 Channel A Vref	R6D4: 0.9 V	Vref incorrect: check resistor values
2	MCHDDR2 Channel B Vref	R6B3: 0.9 V	Vref incorrect: check resistor values
3	MCH Hublink Vref	R5F11: 0.354 V	Vref incorrect: check resistor values
4	MCH Hublink Vswing	R5F8: 0.804 V	Vswing incorrect: check resistor values
5	ICH Hublink Vref	R4G7: 0.347 V	Vref incorrect: check resistor values
6	ICH Hublink Vswing	R4G4: 0.696 V	Vswing incorrect: check resistor values
7	CPU0 VTT Vref (Back side of board)	R2U5: 0.775 V R2V2: 0.775 V	Vref incorrect: check resistor values
8	CPU1 VTT Vref (Back side of board)	R4U5: 0.754 R5V1: 0.754	Vref incorrect: check resistor values
9	MCH VTT Vref	R6F2: 0.775 V	Vref incorrect: check resistor values
10	DIMM A DDR2 Vref	R3M1: 0.9 V	Vref incorrect: check resistor values
11	DIMM B DDR2 Vref	R2M1: 0.9 V	Vref incorrect: check resistor values



7.0 Heatsink Assembly


This section provides heatsink assembly instructions for the Intel® Xeon® Processor with 800 MHz System Bus, Intel® E7520 Chipset, and Intel® 6300ESB ICH Development Kit:

Components requiring post-secondary heat sink assembly are listed in [Table 9](#).

Table 9. Components Requiring Heat Sink Assembly

Component	Quantity per Board	Heat Sink Manufacturer	Part Number	Comments
Processors (See Figure 11 .)	Up to 2	Cooler Master	E3W-N73CS-I1	Active heat sink + back plate.

Figure 11. Components Requiring Heat Sink Assembly






7.1 Processor Heat Sink Installation Instructions

Note: Tools/items needed include Phillips screwdriver, disposable towels, and isopropyl alcohol.

1. Ensure the processor is firmly seated in the socket and the socket latch is closed. (See Figure 12.)


Figure 12. Inserting Processor in Socket



2. Clean the processor's top surface with a clean towel and isopropyl alcohol. (See Figure 13.)




Figure 13. Cleaning the Processor Surface



3. Insert the processor heat sink back plate into the four mounting holes near the processor. The back plate is assembled to the back side of the PCB. (See Figure 14.)


Figure 14. Installing the Processor Backplate






4. Remove the protective covers from the processor heat sink. There is a cover that protects the fan, and another that protects the preapplied thermal interface material on the bottom of the heat sink base. (See Figure 15.)

Figure 15. Removing the Protective Covers



5. Place the heat sink on top of the CPU and align the four screws to the threads of the backplate.

Figure 16. Installing the Heatsink





6. Using a Phillips screwdriver, tighten the screws in the pattern indicated in [Figure 16](#). The screws are shoulder screws and will stop threading once completely tightened.
7. Plug the fan connector into the nearest fan connector on the PCB.
8. If applicable, repeat this process for the second processor.