

# Intel® Storage System JBOD 2000 Family

## *Hardware Guide*



Revision 1.05

July 2013

Enterprise Platforms and Services Division

---

## ***Revision History***

Date	Revision Number	Modifications
December 2012	0.9	Pre-production release.
March 2013	1.0	First release.
July 2013	1.05	Removed the Chapter 9 and Appendix A.

## *Disclaimers*

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

A "Mission Critical Application" is any application in which failure of the Intel Product could result, directly or indirectly, in personal injury or death. SHOULD YOU PURCHASE OR USE INTEL'S PRODUCTS FOR ANY SUCH MISSION CRITICAL APPLICATION, YOU SHALL INDEMNIFY AND HOLD INTEL AND ITS SUBSIDIARIES, SUBCONTRACTORS AND AFFILIATES, AND THE DIRECTORS, OFFICERS, AND EMPLOYEES OF EACH, HARMLESS AGAINST ALL CLAIMS COSTS, DAMAGES, AND EXPENSES AND REASONABLE ATTORNEYS' FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM OF PRODUCT LIABILITY, PERSONAL INJURY, OR DEATH ARISING IN ANY WAY OUT OF SUCH MISSION CRITICAL APPLICATION, WHETHER OR NOT INTEL OR ITS SUBCONTRACTOR WAS NEGLIGENT IN THE DESIGN, MANUFACTURE, OR WARNING OF THE INTEL PRODUCT OR ANY OF ITS PARTS.

Intel may make changes to specifications and product descriptions at any time, without notice. Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined". Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them. The information here is subject to change without notice. Do not finalize a design with this information.

The products described in this document may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Contact your local Intel sales office or your distributor to obtain the latest specifications and before placing your product order.

Copies of documents which have an order number and are referenced in this document, or other Intel literature, may be obtained by calling 1-800-548-4725, or go to: <http://www.intel.com/design/literature>.

Intel warrants that this product will perform to its published specifications. However, all computer systems are inherently subject to unpredictable system behavior under various environmental and other conditions.

This product is not intended to be the sole source for any critical data and the user must maintain a verified backup. Failure to do so or to comply with other user notices in the product user guide and specification documents may result in loss of or access to data.

## Table of Contents

<b>1. Introduction .....</b>	<b>1</b>
1.1 Server Product Use Disclaimer.....	1
1.2 Product Errata.....	1
<b>2. Product Family Overview .....</b>	<b>2</b>
2.1 Chassis Dimensions .....	3
2.2 System Level Environmental Limits.....	4
2.3 System Features and Options Overview .....	6
2.3.1 Hot-swap Hard Drive Bay and Front Panel Options .....	6
2.3.2 Back Panel Features .....	7
2.3.3 Front Panel Options.....	7
2.4 Expander Board.....	8
2.4.1 36-Port Internal Intel® RAID Expander Cards .....	8
2.5 Power Distribution Board (PDB) .....	10
2.6 Available Front Bezel Support .....	14
2.7 Available Rack and Cabinet Mounting Kit Options .....	15
<b>3. Power Subsystem .....</b>	<b>16</b>
3.1 Mechanical Overview.....	17
3.2 Power Connectors .....	18
3.2.1 Power Supply Module Card Edge Connector .....	18
3.2.2 Hot-swap Backplane Power Connector .....	19
3.3 Power Supply Module Efficiency .....	19
3.4 AC Power Cord Specification Requirements .....	19
3.5 AC Input Specifications.....	20
3.5.1 Power Factor .....	20
3.5.2 AC Input Voltage Specification .....	20
3.5.3 AC Line Isolation Requirements .....	20
3.5.4 AC Line Dropout/Holdup.....	20
3.5.5 AC Line Fuse .....	21
3.5.6 AC Inrush.....	21
3.5.7 AC Line Transient Specification.....	21
3.5.8 Susceptibility Requirements .....	22
3.5.9 Electrostatic Discharge Susceptibility .....	22
3.5.10 Fast Transient/Burst .....	22
3.5.11 Radiated Immunity.....	22
3.5.12 Surge Immunity.....	22
3.5.13 Power Recovery .....	23
3.5.14 Voltage Interruptions.....	23
3.5.15 Protection Circuits.....	23
3.5.16 Over Current Protection (OCP).....	23

3.5.17	Over Voltage Protection (OVP).....	23
3.5.18	Over Temperature Protection (OTP) .....	24
3.6	Cold Redundancy Support.....	25
3.6.1	Powering on Cold Standby Supplies to Maintain Best Efficiency .....	25
3.6.2	Powering on Cold Standby Supplies during a Fault or Over Current Condition ....	26
3.6.3	Power Supply Turn On Function.....	26
3.7	Power Supply Status LED .....	27
<b>4.</b>	<b>Thermal Management .....</b>	<b>28</b>
4.1	Thermal Operation and Configuration Requirements .....	28
4.2	Thermal Management Overview.....	28
4.3	Thermal Sensor Input for Fan Speed Control .....	29
4.4	System Fans.....	29
4.5	Power Supply Module Fan.....	31
<b>5.</b>	<b>System Storage and Peripheral Drive Bays Overview.....</b>	<b>32</b>
5.1	2.5" Hard Disk Drive Support.....	32
5.1.1	2.5" Drive Hot-Swap Backplane Overview.....	34
5.1.2	Cypress* CY8C22545 Enclosure Management Controller .....	35
5.2	3.5" Hard Disk Drive Support.....	36
5.2.1	3.5" Drive Hot-Swap Backplane Overview.....	37
5.2.2	Cypress* CY8C22545 Enclosure Management Controller .....	38
<b>6.</b>	<b>Storage Controller Options Overview .....</b>	<b>39</b>
6.1	External SAS Controller Support .....	39
6.2	Intel® SAS Expander Support .....	39
6.2.1	Single-port Configuration .....	40
6.2.2	Dual-port Configuration.....	42
<b>7.</b>	<b>JBOD SAS Adapter Overview .....</b>	<b>43</b>
7.1	JBOD SAS Converter Port Numbering .....	43
7.2	Pin-out .....	44
<b>8.</b>	<b>Front Panel Overview.....</b>	<b>45</b>
8.1	Front Panel Features .....	45
	<b>Reference Documents .....</b>	<b>47</b>

## List of Figures

Figure 1. Product Drawing .....	2
Figure 2. Chassis Dimensions .....	3
Figure 3. System Components Overview .....	6
Figure 4. 3.5" Hard Drive Bay – 12-Drive Configuration .....	6
Figure 5. 2.5" Hard Drive Bay – 24-Drive Configuration .....	6
Figure 6. Back Panel Feature Identification .....	7
Figure 7. Front Panel Options .....	7
Figure 8. Internal SAS Expander Location.....	8
Figure 9. Internal 36-Port SAS Expander Card (RES2CV360).....	9
Figure 10. 36-Port Expander SAS Connector/Drive Identification Block Diagram .....	9
Figure 11. Power Distribution Board (PDB) .....	10
Figure 12. PDB Component Placement.....	11
Figure 13. Fan Fault LED Block Diagram .....	13
Figure 14. Optional Front Bezel (Intel Product Order Code: A2UBEZEL) .....	14
Figure 15. Front Bezel Assembly .....	14
Figure 16 Power Supply Assembly .....	16
Figure 17. Power Supply Module Mechanical Drawing .....	17
Figure 18. Power Supply Module.....	17
Figure 19. AC Power Supply – Connector View .....	17
Figure 20. AC Power Cord.....	19
Figure 21. System Fan Identification .....	29
Figure 22. System Fan Assembly .....	30
Figure 23. 2.5" Hard Drive Bay – 24-Drive Configuration .....	32
Figure 24. Insert 2.5" Drive Tray .....	32
Figure 25. Status and Activity LED on 2.5" Drive Tray .....	33
Figure 26. 2.5" Hot-Swap Backplane and Drive Bay Assembly.....	34
Figure 27. SFF-8482 Connector on HSBP .....	34
Figure 28. Components on HSBP.....	35
Figure 29. 3.5" Hard Drive Bay – 12-Drive Configuration .....	36
Figure 30. 3.5" Drive Tray Assembly .....	36
Figure 31. Status and Activity LED on 3.5" Drive Tray .....	36
Figure 32. 3.5" Hot-Swap Backplane and Drive Bay Assembly.....	37
Figure 33. SFF-8482 Connector on 3.5" HSBP .....	37
Figure 34. Components on 3.5" HSBP .....	38
Figure 35. 2U 12x3.5" Single-port JBOD Interconnect Diagram .....	40
Figure 36. 2U 24x2.5" Single-port JBOD Interconnect Diagram.....	41
Figure 37. 2U 24x2.5" Dual-port JBOD Interconnect Diagram.....	42
Figure 38. JBOD SAS Adapter SAS Port Numbering .....	43
Figure 39. Front Panel Options.....	45

## List of Tables

Table 1. System Feature Set .....	2
Table 2. System Environmental Limits Summary .....	4
Table 3. Power Supply Module Output Power Connector Pin-out .....	18
Table 4. Hot-swap Backplane Power Connector Pin-out (“HSBP PWR”) .....	19
Table 5. 460 Watt Power Supply Efficiency (Gold) .....	19
Table 6. AC Power Cord Specifications .....	19
Table 7. Power Factor .....	20
Table 8. AC Input Voltage Range .....	20
Table 9. AC Line Dropout/Holdup .....	21
Table 10. AC Line Sag Transient Performance .....	21
Table 11. AC Line Surge Transient Performance .....	22
Table 12. Performance Criteria .....	22
Table 13. 460 Watt Power Supply Over Current Protection .....	23
Table 14. Over Voltage Protection (OVP) Limits .....	24
Table 15. Example Load Share Threshold for Activating Supplies .....	25
Table 16. LED Indicators .....	27
Table 17. System Fan Connector Pin-out .....	30
Table 18. Drive Status LED States .....	33
Table 19. Drive Activity LED States .....	33
Table 20. Status LED Status .....	36
Table 21. Activity LED Status .....	37
Table 22. SGPIO Headers Pin-out .....	44
Table 23. System Status LED State Definitions .....	45
Table 24. Power LED Functional States .....	46

**< This page intentionally left blank. >**



# 1. Introduction

---

This Hardware Guide provides system-level information for the Intel® Storage System JBOD 2000 Family.

This document describes the functions and features of the JBOD products that include the chassis layout, system boards, power subsystem, cooling subsystem, storage subsystem options, and available installable options.

This document is divided into the following chapters:

- Chapter 1 – Introduction
- Chapter 2 – Product Family Overview
- Chapter 3 – Power Subsystem
- Chapter 4 – Thermal Management
- Chapter 5 – System Storage and Peripheral Drive Bays Overview
- Chapter 6 – Storage Controller Options Overview
- Chapter 7 – JBOD SAS Adapter Overview
- Chapter 8 – Front Panel Overview
- Reference Documents

## 1.1 Server Product Use Disclaimer

It is the responsibility of the system integrator who chooses not to use Intel-developed server building blocks to consult vendor datasheets and operating parameters to determine the amount of airflow required for their specific application and environmental conditions. Intel Corporation cannot be held responsible if components fail to operate correctly when used outside any of their published operating or non-operating limits.

## 1.2 Product Errata

The products described in this document may contain design defects or errors known as errata that may cause the products to deviate from published specifications. Product errata are documented in the *Intel® Storage System JBOD 2000 Family Monthly Specification Update*, which can be downloaded from <http://www.intel.com>.

## 2. Product Family Overview


This generation of Intel® Storage System JBOD 2000 Family offers a variety of options to meet the configuration requirements of high-density high-performance computing environments. The Intel® Storage System JBOD 2000 Family is comprised of three product offerings.

Note: The following table lists the features common to the Intel® Storage System JBOD 2000 Family. Features that are unique to one product in the family will be identified by denoting the full JBOD Product Code name.

Table 1. System Feature Set

Intel® Storage System JBOD 2000 Family	Description
JBOD2224S2DP	2U JBOD supports 24 x 2.5" drives, with a dual-port backplane.
JBOD2224S2SP	2U JBOD supports 24 x 2.5" drives, with a single-port backplane.
JBOD2312S2SP	2U JBOD supports 12 x 3.5" drives, with a single-port backplane.

This chapter provides a high-level overview of the Intel® Storage System JBOD 2000 Family features and available options supported in different JBOD SKUs. Greater detail for each major system component or feature is provided in the following chapters.



AF006049

Figure 1. Product Drawing

## 2.1 Chassis Dimensions




Figure 2. Chassis Dimensions

## 2.2 System Level Environmental Limits

To keep the system operating within supported maximum thermal limits, the system must meet the following operating and configuration guidelines:

- The system operating ambient is designed for sustained operation up to 35°C (ASHRAE Class A2) with short-term excursion-based operation up to 45°C (ASHRAE Class A4).
  - The system can operate up to 40°C (ASHRAE Class A3) for up to 900 hours per year.
  - The system can operate up to 45°C (ASHRAE Class A4) for up to 90 hours per year.
  - When operating within the extended operating temperature range, the system performance may be impacted.
  - There is no system reliability impact when operating at the extended temperature range within the approved limits.

The following table defines the system-level operating and non-operating environmental limits.

Table 2. System Environmental Limits Summary

Parameter		Limits
Temperature		
	Operating	ASHRAE Class A2 – Continuous Operation. 10°C to 35°C <sup>1</sup> (50°F to 95°F) with the maximum rate of change not to exceed 10°C per hour.
		ASHRAE Class A3 – Includes operation up to 40°C for up to 900 hrs per year.
		ASHRAE Class A4 – Includes operation up to 45°C for up to 90 hrs per year.
	Shipping	-40°C to 70°C (-40°F to 158°F)
Altitude		
	Operating	Support operation up to 3050m with ASHRAE class deratings.
Humidity		
	Shipping	50% to 90%, non-condensing with a maximum wet bulb of 28°C (at temperatures from 25°C to 35°C)
Shock		
	Operating	Half sine, <a href="#">2g</a> , 11 mSec
	Unpackaged	Trapezoidal, <a href="#">25g</a> , velocity change is based on packaged weight
	Packaged	Product Weight: ≥ 40 to < 80 Non-palletized Free Fall Height = 18 inches Palletized (single product) Free Fall Height = NA
Vibration		
	Unpackaged	5 Hz to 500 Hz 2.20 g RMS random
	Packaged	5 Hz to 500 Hz 1.09 g RMS random
AC-DC		
	Voltage	90 V AC to 132 V AC and 180 V AC to 264 V AC
	Frequency	47 Hz to 63 Hz
	Source Interrupt	No loss of data for power line drop-out of 12 mSec
	Surge Non-operating and operating	Unidirectional

Parameter		Limits			
	Line to earth Only	AC Leads	2.0 kV		
		I/O Leads	1.0 kV		
		DC Leads	0.5 kV		
ESD					
	Air Discharged	12.0 kV			
	Contact Discharge	8.0 kV			
Acoustics Sound Power Measured					
	Power in Watts	<300 W	≥300 W	≥600 W	≥1000 W
	Servers/Rack Mount BA	7.0	7.0	7.0	7.0

**Note:**


- Intel Corporation server boards contain a number of high-density VLSI and power delivery components that need adequate airflow to cool. Intel ensures through its own chassis development and testing that when Intel server building blocks are used together, the fully integrated system will meet the intended thermal requirements of these components. It is the responsibility of the system integrator who chooses not to use Intel developed server building blocks to consult vendor datasheets and operating parameters to determine the amount of airflow required for their specific application and environmental conditions. Intel Corporation cannot be held responsible if components fail or the server board does not operate correctly when used outside any of its published operating or non-operating limits.

---

**Disclaimer Note:** Intel ensures the unpackaged server board and system meet the shock requirement mentioned above through its own chassis development and system configuration. It is the responsibility of the system integrator to determine the proper shock level of the board and system if the system integrator chooses different system configuration or different chassis. Intel Corporation cannot be held responsible, if components fail or the server board does not operate correctly when used outside any of its published operating or non-operating limits.

---


## 2.3 System Features and Options Overview



AF006061


Figure 3. System Components Overview

### 2.3.1 Hot-swap Hard Drive Bay and Front Panel Options



AF004299

Figure 4. 3.5" Hard Drive Bay – 12-Drive Configuration



AF004297

Figure 5. 2.5" Hard Drive Bay – 24-Drive Configuration

### 2.3.2 Back Panel Features




Figure 6. Back Panel Feature Identification

### 2.3.3 Front Panel Options




Figure 7. Front Panel Options

Label	Description	Label	Description
A	Non-functional	F	System Status LED
B	Non-functional	G	Power Button w/Integrated LED
C	Non-functional	H	Non-functional
D	Non-functional	I	Non-functional
E	Non-functional	J	Non-functional


## 2.4 Expander Board

Following are features of the Intel® RAID Expander:

- SAS protocol, described in the Serial Attached SCSI (SAS) Standard, version 2.0
- Serial SCSI Protocol (SSP) to enable the communication with other SAS devices
- Serial Tunneling Protocol (STP) support for SATA II through expander interfaces
- Serial Management Protocol (SMP) to share topology management information with expanders
- Supports SES for enclosure management
- Output mini-SAS connectors support sideband SGPIO as per SFF-8485 specification
- Supports both Serial Attached SCSI and Serial ATA device targets
- 6.0 Gbit/s, 3.0 Gbit/s, and 1.5 Gbit/s data transfer rates
- SFF-8087 mini-SAS connectors
- Provides a low-latency connection to create and maintain transparent access to each connected SAS/SATA physical drive
- Staggered spin-up
- Hot Plug
- Native Command Queuing
- Allows multiple initiators to address a single target (in a failover configuration)

### 2.4.1 36-Port Internal Intel® RAID Expander Cards

All JBOD SKUs use the 36-port SAS expander card.



AF006064

Figure 8. Internal SAS Expander Location



The following diagram is used to help identify the mini-SAS connectors found on the SAS expander cards. Take care when connecting the connectors from the SAS expander to the connectors on the backplane because each connector is pre-programmed at the factory to provide specific drive identification mapping. Improper connections may provide undesirable drive mappings. By default, the Intel® Storage System JBOD 2000 Family has all mini-SAS cables connected.




Figure 9. Internal 36-Port SAS Expander Card (RES2CV360)




Figure 10. 36-Port Expander SAS Connector/Drive Identification Block Diagram

Label	Description	Label	Description
A	N/A	F	To backplane ports 0-3
B	To mini-SAS converter	G	To backplane ports 20-23
C	To mini-SAS converter	H	To backplane ports 12-15
D	To backplane ports 16-19	I	To backplane ports 4-7
E	To backplane ports 8-11	J	36-port SAS 6Gb expander

## 2.5 Power Distribution Board (PDB)




Figure 11. Power Distribution Board (PDB)




Figure 12. PDB Component Placement

Label	Description	Label	Description
A	HSBP power header	F	2x15-pin storage mini front panel header
B	Expander SES-2 header	G	2x12-pin front panel header
C	Expander power header	H	1x5 aux header
D	FAN header	J	2x12 SSI power connector
E	HSBP power header	K	power supply connector

The PDB provides power from the power supply modules to the JBOD components, and provides thermal monitoring and fan control. Following are the features of the PDB:

- The PDB connects to the power supply canister through two CRPS card edge connectors.
- Optional 2x12-pin SSI and 1x5-pin SSI power control headers (for potential future use with 4U JBOD fixed power supply).
- Power for up to two internal 36-port SAS expander cards (RES2CV360) for the 2U JBOD with two additional connectors for future use.
- Two 2x4pin 12V power headers and an additional two 2x4-pin 12V power headers for future use. Each cable is used to connect power to a single 12x 3.5" HSBP or up to three 8x 2.5" HSBPs.
- Support for hot-swap redundant fan speed control solutions up to three system fans and identification of fan failures at front panel fault LED indicator with communication over SES2 interface to host PC.
- SMB interface for communicating enclosure status through the expander board to the host system external host controller via SES interface. Monitoring capabilities include:
  - Fan tachs
  - 12V voltage out from PSU
  - 12V current from PSU
  - Temperature on front panel, HDDs, and on the board behind drives
  - Ambient overtemp protection: Reported to host system and fan boost only. No shutdown.
  - Degraded (PSU, FAN) state reportable to host system and on JBOD status LED.

The ADT7476 thermal controller on the PDB can measure and control the speed of up to three fans. The controller provides acoustic enhancements to ensure the fans run at the lowest possible speed for the given temperature. The controller interfaces with two remote temp sensors and a local temp sensor built into the chip.

The thermal controller on the PDB is programmed using the SAS expander that comes with the Intel® Storage System JBOD 2000 Family. The SAS expander in the Intel® Storage System JBOD 2000 Family uses a firmware that programs the thermal controller when the system is turned on. If the SAS expander is not plugged into the PDB using the I<sup>2</sup>C cable, the fans will run at 100% and the thermal controller will not be programmed correctly.

The cable must be connected to the I<sup>2</sup>C port B (Port C will not program the PDB) on the expander board and then either of the I<sup>2</sup>C connectors on the PDB before the system is turned on.

If the fan runs at 100% at room temperature, there is an issue with the SMBUS connection, the SAS expander not getting power, or the incorrect firmware being on the expander.

When a fan fails in the Intel® Storage System JBOD 2000 Family, an interrupt register bit is set in the ADT7476 thermal controller that signals the fan fault (register shown below). The LSI expander chip on the SAS expander monitors this register. When a fan fault bit is set in the interrupt register, this information is sent to the host system through SES. The ADT7476

controller also sends a signal out of its GPIOs to light the LED on the failed fan’s hot-swap housing, which makes replacing/diagnosing the failed fan much easier.

Interrupt Register 2 for ADT7476 (Bits 2, 3, and 4 used for fan faults):

Addr	R/W	Desc	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	De-fault	Lock-able
0x42	R	Interrupt Status Register 2	D2	D1	F4P	FAN3	FAN2	FAN1	OVT	12 V/VC	0x00	-




Figure 13. Fan Fault LED Block Diagram

## 2.6 Available Front Bezel Support

The optional front bezel is made of molded plastic and uses a snap-on design. When installed, its design allows for maximum airflow to maintain system cooling requirements. The face of the bezel assembly includes optional snap-in identification badge and wave (as shown) features to allow for customization.




Figure 14. Optional Front Bezel (Intel Product Order Code: A2UBEZEL)




Figure 15. Front Bezel Assembly

## 2.7 Available Rack and Cabinet Mounting Kit Options

- Tool-less rack mount rail kit (Intel Product Code: AXXPRAIL)
  - 1U and 2U compatible
  - 65 lbs max support weight
  - Tool-less installation
  - Full extension from the rack
  - Drop-in-system installation
  - Optional cable management arm support
  
- Value rack mount rail kit (Intel Product Code: AXXELVRAIL)
  - 2U to 4U compatible: 438-mm wide Intel chassis support
  - 130 lbs max support weight
  - Tool-less chassis attach
  - Tools required to attach the rails to the rack
  - 1/2 extension: Extended inner slide member from the rack

---

**Advisory Note:** The AXXELVRAIL value rack mount rail kit is not designed to support shipment of the server system when installed in a rack.

---

- Cable management arm (Intel Product Code: AXX1U2UCMA; supported with AXXPRAIL only)
- 2-post fixed mount bracket kit (Intel Product Code: AXX2POSTBRCKT)

### 3. Power Subsystem

This chapter provides a high-level overview of the power management features and specification data for the power supply options available for Intel® Storage System JBOD 2000 Family. Specification variations will be identified for each supported power supply.

Although this system cannot be loaded high enough to hit this mode (2+0), the Intel® Storage System JBOD 2000 Family can have up to two power supply modules installed, supporting the following power supply configurations: 1+0 (single power supply), 1+1 redundant power, and 2+0 combined power (non-redundant). The 1+1 redundant power and 2+0 combined power configurations are automatically configured depending on the total power draw of the system. If the total system power draw exceeds the power capacity of a single power supply module, power from the second power supply module will be utilized. If this occurs, power redundancy is lost. In a 2+0 power configuration, the total power available may be less than twice the rated power of the installed power supply modules due to the amount of heat produced with both supplies providing peak power. If the system thermals exceed programmed limits, platform management will attempt to keep the system operational. Thermal support is open loop based on the ambient temp sensor on the front panel.

The only power supply option validated for the Intel® Storage System JBOD 2000 Family is the 460W AC PS. The 750 W AC PS will fit and operate, but will not be validated in the JBOD or plan of record.

The power supplies are modular, allowing for tool-less insertion and extraction from a bay in the back of the chassis. When inserted, the card edge connector of the power supply mates blindly to a matching slot connector on the PDB board.

In the event of a power supply failure, the redundant 1+1 power supply configuration supports the hot-swap extraction and insertion.




Figure 16 Power Supply Assembly

The AC input is auto-ranging and power factor corrected.



### 3.1 Mechanical Overview

The physical size of the power supply enclosure is 39/40mm x 74mm x 185mm. The power supply contains a single 40-mm fan. The power supply has a card edge output that interfaces with a 2x25 card edge connector in the system. The AC plugs directly into the external face of the power supply.




Figure 17. Power Supply Module Mechanical Drawing




Figure 18. Power Supply Module



Figure 19. AC Power Supply – Connector View

## 3.2 Power Connectors

### 3.2.1 Power Supply Module Card Edge Connector

Each power supply module has a single 2x25 card edge output connection that plugs directly into a matching slot connector on the server board. The connector provides both power and communication signals to the server board. The following table defines the connector pin-out.

Table 3. Power Supply Module Output Power Connector Pin-out

Pin	Name	Pin	Name
A1	GND	B1	GND
A2	GND	B2	GND
A3	GND	B3	GND
A4	GND	B4	GND
A5	GND	B5	GND
A6	GND	B6	GND
A7	GND	B7	GND
A8	GND	B8	GND
A9	GND	B9	GND
A10	+12V	B10	+12V
A11	+12V	B11	+12V
A12	+12V	B12	+12V
A13	+12V	B13	+12V
A14	+12V	B14	+12V
A15	+12V	B15	+12V
A16	+12V	B16	+12V
A17	+12V	B17	+12V
A18	+12V	B18	+12V
A19	PMBus SDA	B19	A0 (SMBus address)
A20	PMBus SCL	B20	A1 (SMBus address)
A21	PSON	B21	12V stby
A22	SMBAlert#	B22	Cold Redundancy Bus
A23	Return Sense	B23	12V Load Share Bus
A24	+12V Remote Sense	B24	No Connect
A25	PWOK	B25	Compatibility Check pin*

The JBOD's PDB provides several connectors to provide power to various system options. The following sub-sections identify the location, provide the pin-out definition, and provide a brief usage description for each.

### 3.2.2 Hot-swap Backplane Power Connector

The JDOB's PDB board includes four white 2x4-pin power connectors used to provide power to the hot-swap backplanes. On the JBOD PDB, this connector is labeled as "HSBP PWR". The following table provides the pin-out for this connector.

Table 4. Hot-swap Backplane Power Connector Pin-out ("HSBP PWR")

Pin	Signal Description	Pin	Signal Description
1	Ground	5	P12V_240VA
2	Ground	6	P12V_240VA
3	Ground	7	P12V_240VA
4	Ground	8	P12V_240VA

### 3.3 Power Supply Module Efficiency

The following table provides the required minimum efficiency level at various loading conditions. These are provided at four different load levels: 100%, 50%, 20%, and 10%. Efficiency is tested over an AC input voltage range of 115 VAC to 220 VAC.

Table 5. 460 Watt Power Supply Efficiency (Gold)

Loading	100% of Maximum	50% of Maximum	20% of Maximum	10% of Maximum
Minimum efficiency	88%	92%	88%	80%

### 3.4 AC Power Cord Specification Requirements

The AC power cord used meets the specification requirements listed in the following table.

Table 6. AC Power Cord Specifications

Cable Type	SJT
Wire Size	16 AWG
Temperature Rating	105°C
Amperage Rating	13 A
Voltage Rating	125 V




Figure 20. AC Power Cord

## 3.5 AC Input Specifications

### 3.5.1 Power Factor

The power supply meets the power factor requirements stated in the Energy Star Program Requirements for Computer Servers. These requirements are stated below.

Table 7. Power Factor

Output Power	10% Load	20% Load	50% Load	100% Load
Power factor	> 0.65	> 0.80	> 0.90	> 0.95

Tested at 230VAC, 50Hz and 60Hz and 115VAC, 60Hz

### 3.5.2 AC Input Voltage Specification

The power supply operates within all specified limits over the following input voltage range. Harmonic distortion of up to 10% of the rated line voltage does not cause the power supply to go out of specified limits. Application of an input voltage below 85VAC does not cause damage to the power supply, including a blown fuse.

Table 8. AC Input Voltage Range

Parameter	Min	Rated	Vmax	Start-up VAC	Power-off VAC
Voltage (110)	90 Vrms	100-127 Vrms	140 Vrms	85VAC +/-4VAC	70VAC +/-5VAC
Voltage (220)	180 Vrms	200-240 Vrms	264 Vrms		
Frequency	47 Hz	50/60 Hz	63 Hz		

1. The maximum input current at low input voltage range is measured at 90VAC, at max load.
2. The maximum input current at high input voltage range is measured at 180VAC, at max load.
3. This requirement is not to be used for determining agency input current markings.

### 3.5.3 AC Line Isolation Requirements

The power supply meets all safety agency requirements for dielectric strength. Transformers' isolation between primary and secondary windings complies with the 3000VAC (4242VDC) dielectric strength criteria. If the working voltage between primary and secondary dictates a higher dielectric strength test voltage, the highest test voltage will be used. In addition the insulation system complies with reinforced insulation per safety standard IEC 950. Separation between the primary and secondary circuits, and primary to ground circuits, complies with the IEC 950 spacing requirements.

### 3.5.4 AC Line Dropout/Holdup

An AC line dropout is defined to be when the AC input drops to 0VAC at any phase of the AC line for any length of time. During an AC dropout the power supply meets dynamic voltage regulation requirements. An AC line dropout of any duration does not cause tripping of control signals or protection circuits. If the AC dropout lasts longer than the holdup time, the power supply will recover and meet all turn-on requirements. The power supply meets the AC dropout requirement over rated AC voltages and frequencies. A dropout of the AC line for any duration does not cause damage to the power supply.

Table 9. AC Line Dropout/Holdup

Loading	Holdup Time
70%	12msec

### 3.5.4.1 AC Line 12VSB Holdup

The 12VSB output voltage stays in regulation under its full load (static or dynamic) during an AC dropout of **70ms min** (=12VSB holdup time) whether the power supply is in ON or OFF state (PSON asserted or de-asserted).

### 3.5.5 AC Line Fuse

The power supply has one line fused in the **single line fuse** on the line (Hot) wire of the AC input. The line fusing is acceptable for all safety agency requirements. The input fuse is a slow blow type. The AC inrush current does not cause the AC line fuse to blow under any conditions. All protection circuits in the power supply will not cause the AC fuse to blow unless a component in the power supply has failed. This includes DC output load short conditions.

### 3.5.6 AC Inrush

The AC line inrush current does not exceed **55A peak**, for up to one-quarter of the AC cycle, after which, the input current is no more than the specified maximum input current. The peak inrush current is less than the ratings of its critical components (including input fuse, bulk rectifiers, and surge limiting device).

The power supply meets the inrush requirements for any rated AC voltage, during turn-on at any phase of AC voltage, during a single cycle AC dropout condition as well as upon recovery after AC dropout of any duration, and over the specified temperature range ( $T_{op}$ ).

### 3.5.7 AC Line Transient Specification

The AC line transient conditions are defined as sag and surge conditions. Sag conditions are also commonly referred to as “brownout”; these conditions are defined as the conditions when the AC line voltage drops below nominal voltage. Surge conditions are defined as the conditions when the AC line voltage rises above nominal voltage.

The power supply meets the requirements under the following AC line sag and surge conditions.

Table 10. AC Line Sag Transient Performance

AC Line Sag (10sec interval between each sagging)				
Duration	Sag	Operating AC Voltage	Line Frequency	Performance Criteria
0 to 1/2 AC cycle	95%	Nominal AC Voltage ranges	50/60 Hz	No loss of function or performance
> 1 AC cycle	> 30%	Nominal AC Voltage ranges	50/60 Hz	Loss of function acceptable, self recoverable

Table 11. AC Line Surge Transient Performance

AC Line Surge				
Duration	Surge	Operating AC Voltage	Line Frequency	Performance Criteria
Continuous	10%	Nominal AC Voltages	50/60 Hz	No loss of function or performance
0 to ½ AC cycle	30%	Mid-point of nominal AC Voltages	50/60 Hz	No loss of function or performance

### 3.5.8 Susceptibility Requirements

The power supply meets the following electrical immunity requirements when connected to a cage with an external EMI filter that meets the criteria defined in the SSI document *EPS Power Supply Specification*. For further information on Intel standards, request a copy of the *Intel Environmental Standards Handbook*.

Table 12. Performance Criteria

Level	Description
A	The apparatus continues to operate as intended. No degradation of performance.
B	The apparatus continues to operate as intended. No degradation of performance beyond spec limits.
C	Temporary loss of function is allowed provided that the function is self-recoverable or can be restored by the operation of the controls.

### 3.5.9 Electrostatic Discharge Susceptibility

The power supply complies with the limits defined in EN 55024: 1998/A1: 2001/A2: 2003 using the IEC 61000-4-2: Edition 1.2: 2001-04 test standard and performance criteria B defined in Annex B of CISPR 24.

### 3.5.10 Fast Transient/Burst

The power supply complies with the limits defined in EN 55024: 1998/A1: 2001/A2: 2003 using the IEC 61000-4-4: Second edition: 2004-07 test standard and performance criteria B defined in Annex B of CISPR 24.

### 3.5.11 Radiated Immunity

The power supply complies with the limits defined in EN 55024: 1998/A1: 2001/A2: 2003 using the IEC 61000-4-3: Edition 2.1: 2002-09 test standard and performance criteria A defined in Annex B of CISPR 24.

### 3.5.12 Surge Immunity

The power supply is tested with the system for immunity to AC unidirectional wave, 2kV line to ground and 1kV line to line, per EN 55024: 1998/A1: 2001/A2: 2003, EN 61000-4-5: Edition 1.1:2001-04.

The pass criteria include: no unsafe operation is allowed under any condition; all power supply output voltage levels to stay within proper spec levels; no change in operating state or loss of data during and after the test profile; no component damage under any condition.

The power supply complies with the limits defined in EN 55024: 1998/A1: 2001/A2: 2003 using the IEC 61000-4-5: Edition 1.1:2001-04 test standard and performance criteria B defined in Annex B of CISPR 24.

### 3.5.13 Power Recovery

The power supply recovers automatically after an AC power failure. An AC power failure is defined to be any loss of AC power that exceeds the dropout criteria.

### 3.5.14 Voltage Interruptions

The power supply complies with the limits defined in EN 55024: 1998/A1: 2001/A2: 2003 using the IEC 61000-4-11: Second Edition: 2004-03 test standard and performance criteria C defined in Annex B of CISPR 24.

### 3.5.15 Protection Circuits

The protection circuits inside the power supply cause only the power supply's main outputs to shut down. If the power supply latches off due to a protection circuit tripping, an AC cycle OFF for 15 seconds and a PSON# cycle HIGH for one second reset the power supply.

### 3.5.16 Over Current Protection (OCP)

The power supply has a current limit to prevent the outputs from exceeding the values shown in the table below. If the current limit is exceeded, the power supply will shut down and latch off. The latch will be cleared by toggling the PSON# signal or by an AC power interruption. The power supply will not be damaged from repeated power cycling in this condition. 12VSB will be auto-recovered after removing the OCP limit.

Table 13. 460 Watt Power Supply Over Current Protection

Output Voltage	Input Voltage Range	Over Current Limit
+12V	90–264VAC	47A min; 55A max
12VSB	90–264VAC	2A min; 2.5A max

### 3.5.17 Over Voltage Protection (OVP)

The power supply over voltage protection is locally sensed. The power supply will shut down and latch off after an over voltage condition occurs. This latch will be cleared by toggling the PSON# signal or by an AC power interruption. The values are measured at the output of the power supply's connectors. The voltage never exceeds the maximum levels when measured at the power connectors of the power supply connector during any single point of fail. The voltage never trips any lower than the minimum levels when measured at the power connector. 12VSB will be auto-recovered after removing the OVP limit.

Table 14. Over Voltage Protection (OVP) Limits

Output Voltage	Min (V)	Max (V)
+12V	13.3	14.5
12VSB	13.3	14.5

### 3.5.18 Over Temperature Protection (OTP)

The power supply is protected against over temperature conditions caused by loss of fan cooling or excessive ambient temperature. In an OTP condition the PSU will shut down. When the power supply temperature drops to within specified limits, the power supply will restore power automatically, while the 12VSB remains always on. The OTP circuit has a built-in margin so that the power supply will not oscillate on and off due to temperature recovering conditions. The OTP trip level has a minimum of 4°C of ambient temperature margin.



## 3.6 Cold Redundancy Support

Power supplies that support cold redundancy can be enabled to go into a low-power state (that is, cold redundant state) in order to provide increased power usage efficiency when system loads are such that both power supplies are not needed. When the power subsystem is in Cold Redundant mode, only the needed power supply to support the best power delivery efficiency is ON. Any additional power supplies, including the redundant power supply, are in Cold Standby state.

Each power supply has an additional signal that is dedicated to supporting Cold Redundancy, CR\_BUS. This signal is a common bus between all power supplies in the system. CR\_BUS is asserted when there is a fault in any power supply or the power supplies output voltage falls below the  $V_{\text{fault}}$  threshold. Asserting the CR\_BUS signal causes all power supplies in Cold Standby state to power ON.

Enabling power supplies to maintain best efficiency is achieved by looking at the Load Share bus voltage and comparing it to a programmed voltage level via a PMB bus command.

Whenever there is no active power supply on the Cold Redundancy bus driving a HIGH level on the bus, all power supplies are ON no matter their defined Cold Redundant roll (active or Cold Standby). This guarantees that incorrect programming of the Cold Redundancy states of the power supply will never cause the power subsystem to shut down or become over loaded. The default state of the power subsystem is all power supplies ON. There needs to be at least one power supply in Cold Redundant Active state or Standard Redundant state to allow the Cold Standby state power supplies to go into Cold Standby state.

### 3.6.1 Powering on Cold Standby Supplies to Maintain Best Efficiency

Power supplies in Cold Standby state monitor the shared voltage level of the load share signal to sense when it needs to power on. Depending upon which position (1, 2, or 3) the system defines that the power supply to be in the cold standby configuration, the system will slightly change the load share threshold that the power supply will power on at.

Table 15. Example Load Share Threshold for Activating Supplies

	Enable Threshold for $V_{\text{CR\_ON\_EN}}$	Disable Threshold for $V_{\text{CR\_ON\_DIS}}$	CR_BUS De-asserted / Asserted States
Standard Redundancy	NA; Ignore dc/dc_active# signal; power supply is always ON		OK = High Fault = Low
Cold Redundant Active	NA; Ignore dc/dc_active# signal; power supply is always ON		OK = High Fault = Low
Cold Standby 1 (02h)	3.2V (40% of max)	$3.2V \times 0.5 \times 0.9 = 1.44V$	OK = Open Fault = Low
Cold Standby 2 (03h)	5.0V (62% of max)	$5.0V \times 0.67 \times 0.9 = 3.01V$	OK = Open Fault = Low
Cold Standby 3 (04h)	6.7V (84% of max)	$6.7V \times 0.75 \times 0.9 = 4.52V$	OK = Open Fault = Low

**Notes:**

Maximum load share voltage = 8.0V at 100% of rated output power

These are example load share bus thresholds; for a given power supply, these shall be customized to maintain the best efficiency curve for that specific model.

### **3.6.2 Powering on Cold Standby Supplies during a Fault or Over Current Condition**

When an active power supply asserts its CR\_BUS signal (pulling it low), all parallel power supplies in a cold standby mode will power on within 100  $\mu$ sec.

### **3.6.3 Power Supply Turn On Function**

Powering on and off the cold standby power supplies is only controlled by each PSU sensing the  $V_{share}$  bus. After a power supply turns on after crossing the enable threshold, it lowers its threshold to the disable threshold. The system defines the “position” of each power supply in the Cold Redundant operation. It will do this each time the system is powered on, a power supply fails, or a power supply is added to the system.

The system is relied upon to tell each power supply where it resides in the Cold Redundancy scheme.

### 3.7 Power Supply Status LED

There is a single bi-color LED to indicate power supply status. The LED operation is defined in the following table.

Table 16. LED Indicators

Power Supply Condition	LED State
Output ON and OK	Green
No AC power to all power supplies	Off
AC present / Only 12VSB on (PS off) or PS in cold redundant state	1 Hz Blink Green
AC cord unplugged or AC power lost, with a second power supply in parallel still with AC input power	Amber
Power supply warning events where the power supply continues to operate; high temp, high power, high current, slow fan	1 Hz Blink Amber
Power supply critical events causing a shutdown; failure, OCP, OVP, fan fail	Amber
Power supply FW updating	2 Hz Blink Green

## 4. Thermal Management

---

The Intel® Storage System JBOD 2000 Family is designed to operate at external ambient temperatures of between 10°C and 35°C with limited excursion-based operation up to 45°C and limited performance impact. Working with integrated platform management, several features within the system are designed to move air in a front-to-back direction, through the system and over critical components to prevent them from overheating and allow the system to operate with best performance.

The installation and functionality of several JBOD components are used to maintain system thermals. They include up to three managed 60-mm system fans and one integrated 40-mm fan for each installed power supply module. Hard drive carriers can be populated with a hard drive or supplied drive blank.

### 4.1 Thermal Operation and Configuration Requirements

To keep the system operating within supported maximum thermal limits, the system must meet the following operating and configuration guidelines:

- The system operating ambient is designed for sustained operation up to 35°C (ASHRAE Class A2) with short-term excursion-based operation up to 45°C (ASHRAE Class A4).
  - The system can operate up to 40°C (ASHRAE Class A3) for up to 900 hours per year.
  - The system can operate up to 45°C (ASHRAE Class A4) for up to 90 hours per year.
  - System performance may be impacted when operating within the extended operating temperature range.
  - There is no long-term system reliability impact when operating at the extended temperature range within the approved limits.
- All hard drive bays must be populated. Hard drive carriers can be populated with a hard drive or supplied drive blank.
- In single power supply configurations, the second power supply bay must have the supplied filler blank installed at all times.
- The system must be configured with dual power supplies for the system to support fan redundancy.
- The system top cover must be installed at all times when the system is in operation. The only exception to this requirement is to hot replace a failed system fan, in which case the top cover can be removed for no more than three minutes at a time.

### 4.2 Thermal Management Overview

In order to maintain the necessary airflow within the system, all of the previously listed components and top cover need to be properly installed. For best system performance, the external ambient temperature should remain below 35°C and all system fans should be operational. The system is designed for fan redundancy when the system is configured with two power supplies.

#### Altitude

This option sets the proper altitude that the system will be used. Available settings include [300m or less], [301m-900m], [901m-1500m], and [Above 1500m].

Selecting an altitude range that is lower than the actual altitude the system will be operating at, can cause the fan control system to operate less efficiently, leading to higher system thermals and lower system performance. If the altitude range selected is higher than the actual altitude the system will be operating at, the fan control system may provide better cooling but with higher acoustics and higher fan power consumption. If the altitude is not known, selecting a higher altitude is recommended in order to provide sufficient cooling.

---

Note: The feature above may or may not be in effect and depends on the actual thermal characteristics of the specified system.

---

### 4.3 Thermal Sensor Input for Fan Speed Control


The power distribution board uses various sensors as inputs to fan speed control. Some of the sensors are actual physical sensors and some are virtual sensors derived from calculations.

The following thermal sensor is used as an input to fan speed control:

- Front Panel Temperature Sensor

### 4.4 System Fans

Three 60x38-mm fans and an embedded fan for each installed power supply, provide the primary airflow for the system. The system is designed for fan redundancy when configured with two power supply modules. If a single fan fails (system fan or power supply fan), platform management will adjust the airflow of the remaining fans and manage other platform features to maintain system thermals. Fan redundancy is lost if more than one fan is in a failed state.



AF006062

Figure 21. System Fan Identification

The system fan assembly is designed for ease of use and supports several features:

- Each fan is hot-swappable.
- Each fan is designed for tool-less insertion and extraction from the fan assembly. For instructions on installing or removing a fan module, see the *Intel® JBOD 2000 Family Service Guide*.
- Fan speed for each fan is controlled by integrated platform management controlled by the PDB board. When system thermals fluctuate high and low, the PDB firmware will increase or decrease the speeds of specific fans within the fan assembly to regulate system thermals.
- Each fan has a tachometer signal that allows the PDB to monitor its status.
- On top of each fan is an integrated fault LED, although currently this feature is not supported.
- Each fan has a 10-pin wire harness that connects to a matching connector on the PDB.




Figure 22. System Fan Assembly

Table 17. System Fan Connector Pin-out

SYS_FAN 1		SYS_FAN 2		SYS_FAN 3	
Pin#	Signal Description	Pin#	Signal Description	Pin#	Signal Description
1	FAN_TACH1_IN	1	FAN_TACH3_IN	1	FAN_TACH5_IN
2	FAN_BMC_PWM0_R_BUF	2	FAN_BMC_PWM1_R_BUF	2	FAN_BMC_PWM2_R_BUF
3	P12V_FAN	3	P12V_FAN	3	P12V_FAN
4	P12V_FAN	4	P12V_FAN	4	P12V_FAN
5	FAN_TACH0_IN	5	FAN_TACH2_IN	5	FAN_TACH4_IN
6	GROUND	6	GROUND	6	GROUND
7	GROUND	7	GROUND	7	GROUND
8	FAN_SYS0_PRSENT_N	8	FAN_SYS1_PRSENT_N	8	FAN_SYS2_PRSENT_N
9	LED_FAN_FAULT0_R	9	LED_FAN_FAULT1_R	9	LED_FAN_FAULT2_R
10	LED_FAN0	10	LED_FAN1	10	LED_FAN2

## 4.5 Power Supply Module Fan

Each installed power supply module includes one embedded (non-removable) 40-mm fan. It is responsible for airflow through the power supply module. If this fan fails, the power supply will continue to operate until its internal temperature reaches an upper critical limit. The power supply will be protected against over temperature conditions caused by loss of fan cooling or excessive ambient temperature. In an over temperature protection condition, the power supply module will shut down.

## 5. System Storage and Peripheral Drive Bays Overview

The Intel® Storage System JBOD2000 Family supports the following storage device options:

- Hot-swap 2.5" hard disk drives
- Hot-swap 3.5" hard disk drives

### 5.1 2.5" Hard Disk Drive Support

The server is available in 2.5" hard disk configurations of 24 drives as illustrated below.




Figure 23. 2.5" Hard Drive Bay – 24-Drive Configuration

The drive bay can support either SATA or SAS hard disk drives. Mixing of drive types within a common hot-swap backplane is not supported. Systems with multiple hot-swap backplanes can support different drive type configurations as long as the drives attached to a common backplane are the same and the installed controller attached to the given backplane can support the drive type. Hard disk drive type is dependent on the type of host bus controller used, SATA only or SAS.

Each 2.5" hard disk drive is mounted to a drive tray, allowing for hot-swap extraction and insertion. Drive trays have a latching mechanism that is used to extract and insert the drives from the chassis, and lock the tray in place.




Figure 24. Insert 2.5" Drive Tray



Light pipes integrated into the drive tray assembly direct the light emitted from Amber drive status and Green activity LEDs located next to each drive connector on the backplane, to the drive tray faceplate, making them visible from the front of the system.




Figure 25. Status and Activity LED on 2.5" Drive Tray

Table 18. Drive Status LED States

<b>Amber</b>	Off	No access and no fault.
	Solid on	Hard drive fault has occurred.
	Blink	RAID rebuild in progress (1 Hz); Identify (2 Hz).

Table 19. Drive Activity LED States

	Condition	Drive Type	Behavior
<b>Green</b>	Power on with no drive activity	SAS	LED stays on.
		SATA	LED stays off.
	Power on with drive activity	SAS	LED blinks off when processing a command.
		SATA	LED blinks on when processing a command.
	Power on and drive spun down	SAS	LED stays off.
		SATA	LED stays off.
Power on and drive spinning up	SAS	LED blinks.	
	SATA	LED stays off.	

### 5.1.1 2.5" Drive Hot-Swap Backplane Overview

Depending on the number of hard disk drives supported by a given system SKU, a system can be configured with 1, 2, or 3 eight drive backplanes. Each backplane is attached to the back of the drive bay assembly.




Figure 26. 2.5" Hot-Swap Backplane and Drive Bay Assembly

On the front side of each backplane are mounted eight hard disk drive interface connectors (A), each providing both power and I/O signals to the attached hard disk drives.




Figure 27. SFF-8482 Connector on HSBP

On the backside of each backplane are several connectors. The following illustration identifies each.




Figure 28. Components on HSBP

Label	Description
A	SMBus-Out cable connector for multi-backplane support
B	4-port mini-SAS cable connectors
C	SMBus-In cable connector – From the server board or other backplanes
D	Power connector

**A and C** – SMBus Cable Connectors – The backplane includes two 1x5 cable connectors used as a management interface between the server board and the installed backplanes. In systems configured with multiple backplanes, a short jumper cable is attached between backplanes, with connector B used on the first board and connector D used on the second board, extending the SMBus to each installed backplane.

**B** – Multi-port Mini-SAS Cable Connectors – The backplane includes two multi-port mini-SAS cable connectors, each providing SGPIO and I/O signals for four SAS/SATA hard drives on the backplane. Cables can be routed from the matching connectors on the server board, the installed add-in SAS/SATA RAID cards, or optionally installed SAS expander cards for drive configurations of greater than eight hard drives.

**D** – Power Harness Connector – The backplane includes a 2x2 connector supplying power to the backplane. Power is routed to each installed backplane through a multi-connector power cable harness from the server board.

### 5.1.2 Cypress\* CY8C22545 Enclosure Management Controller

The backplanes support enclosure management using a Cypress\* CY8C22545 Programmable System-on-Chip (PSoC\*) device. The CY8C22545 drives the hard drive activity/fault LED and hard drive present signal, and controls hard drive power-up during system power-on.

## 5.2 3.5" Hard Disk Drive Support

The server is available in 3.5" hard disk configurations of 12 drives as illustrated below.




Figure 29. 3.5" Hard Drive Bay – 12-Drive Configuration

The drive bay can support either SATA or SAS hard disk drives. Mixing of drive types within the hard drive bay is not supported. Hard disk drive type is dependent on the type of host bus controller used, SATA only or SAS. Each 3.5" hard disk drive is mounted to a drive tray, allowing for hot-swap extraction and insertion. Drive trays have a latching mechanism that is used to extract and insert the drives from the chassis, and lock the tray in place.




Figure 30. 3.5" Drive Tray Assembly

Light pipes integrated into the drive tray assembly direct the light emitted from Amber drive status and Green activity LEDs located next to each drive connector on the backplane, to the drive tray faceplate, making them visible from the front of the system.



Figure 31. Status and Activity LED on 3.5" Drive Tray

Table 20. Status LED Status

<b>Amber</b>	Off	No access and no fault.
	Solid on	Hard drive fault has occurred.
	Blink	RAID rebuild in progress (1 Hz); Identify (2 Hz).

Table 21. Activity LED Status

	Condition	Drive Type	Behavior
<b>Green</b>	Power on with no drive activity	SAS	LED stays on.
		SATA	LED stays off.
	Power on with drive activity	SAS	LED blinks off when processing a command.
		SATA	LED blinks on when processing a command.
	Power on and drive spun down	SAS	LED stays off.
		SATA	LED stays off.
Power on and drive spinning up	SAS	LED blinks.	
	SATA	LED stays off.	

### 5.2.1 3.5" Drive Hot-Swap Backplane Overview

Systems with 8- or 12-drive configurations have their own unique backplane. Both 8- and 12-drive backplanes share identical features. This section describes the features of both backplanes. Differences between the two will be noted.

The backplanes mount to the back of the drive bay assembly.




Figure 32. 3.5" Hot-Swap Backplane and Drive Bay Assembly

On the front side of each backplane are mounted eight or twelve hard disk drive interface connectors, each providing both power and I/O signals to the attached hard disk drives.




Figure 33. SFF-8482 Connector on 3.5" HSBP

On the backside of each backplane are several connectors. The following illustration identifies each.




Figure 34. Components on 3.5" HSBP

Label	Description
A	4-port mini-SAS connectors
B	Power connectors
C	SMBus connector

**A – 4-port Mini-SAS Connectors** – The backplane includes two or three multi-port mini-SAS cable connectors, each providing SGPIO and I/O signals for four SAS/SATA hard drives on the backplane. Cables can be routed from the matching connectors on the server board, the add-in SAS/SATA RAID cards, or an optionally installed SAS expander card. Each mini-SAS connector includes a silk-screen identifying which drives the connector supports; Drives 0-3, Drives 4-7, and Drives 8-11.

**B – Power Harness Connector** – The backplane includes a 2x2 connector supplying power to the backplane. Power is routed to the backplane through a power cable harness from the server board.

**C – SMBus Cable Connectors** – The backplane includes a 1x5 cable connector used as a management interface to the server board.

### 5.2.2 Cypress\* CY8C22545 Enclosure Management Controller

The backplanes support enclosure management using a Cypress\* CY8C22545 Programmable System-on-Chip (PSoC\*) device. The CY8C22545 drives the hard drive activity/fault LED and hard drive present signal, and controls hard drive power-up during system power-on.

## 6. Storage Controller Options Overview

---

The Intel® Storage System JBOD 2000 Family supports the connection to many different external SAS HBA and SAS RAID controller solutions to achieve single JBOD connection, multiple JBODs daisy chain connection, and failover connections. This chapter provides an overview of the different available options.

### 6.1 External SAS Controller Support

The current and future supported controllers will be referenced via the JBOD 2000 Family THOL or SCT.

SAS connectivity is achieved through the external SAS connectors (SFF8088). Both native SAS HBAs and RAID HBAs are supported.

### 6.2 Intel® SAS Expander Support

The Intel 36-port expander is mounted vertically in the chassis and is designed on LSI's Bobcat expander technology. The expander has nine SFF8087 mini-SAS connectors that connect to either the backplane or the SAS converter boards through SFF8087 to SFF8087 cables. The dual-port backplane version of the JBOD contains two 36-port expanders, and the single-port backplane versions contain one 36-port expander.

### 6.2.1 Single-port Configuration




Figure 35. 2U 12x3.5" Single-port JBOD Interconnect Diagram






Figure 36. 2U 24x2.5" Single-port JBOD Interconnect Diagram

## 6.2.2 Dual-port Configuration




Figure 37. 2U 24x2.5" Dual-port JBOD Interconnect Diagram

## 7. JBOD SAS Adapter Overview

This chapter describes the high-level hardware architecture for the external to internal SAS adapter for the Intel® Storage System JBOD 2000 Family.

The JBOD SAS adapter is an independent product, Intel® 8087-8088 Cable Connector Converter AXXRCVT8788.

The Intel® 8087-8088 Cable Connector Converter AXXRCVT8788 converts two internal SFF8087 x4 mini-SAS connectors to two external SFF8088 SAS x4 connectors. The 8x ports of 6Gb SAS can be supported with this adapter.

The converter includes a PCI mounting bracket that allows the converter to be mounted and retained in a rear panel PCI mounting location.

No power rails, power consumers, or temperature sensors are on the JBOD SAS adapter board.

The adapter board does not support 12Gb dual-port functionality. A new version of this board will be required if 12Gb dual-port infrastructure is available.

### 7.1 JBOD SAS Converter Port Numbering

Following is a suggestion for the JBOD SAS converter board port numbering for internal and external connections.




Figure 38. JBOD SAS Adapter SAS Port Numbering

Item	Description
A1	External SFF 8088 connector. Internally wired to B1.
A2	External SFF 8088 connector. Internally wired to B2.
B1	Internal SFF 8087 connector. Internally wired to A1.
B2	Internal SFF 8087 connector. Internally wired to A2.

## 7.2 Pin-out

See the SAS Gen2 specification for correct pin-out for the SAS internal and external connectors. The connection between the internal mini-SAS and external mini-SAS needs to be one to one direct connection of differential pairs with length matching on the board. The internal mini-SAS connectors should use the controller mini-SAS pin-out. The sideband signals within the internal mini-SAS connectors need to conform to the SFF-8448 specification. You do not need to do the pull-ups or pull-downs on any sideband signals (including sideband 6 and 7) when cabling externally; sidebands are only for potential debug purposes on this board.

See the following pin-out for SGPIO debug headers.

Table 22. SGPIO Headers Pin-out

Ref Des	Description
-	1x5-pin SATA SGPIO
Pin	Signal Description
1	SGPIO_CLOCK_0
2	SGPIO_LOAD_0
3	GND
4	SGPIO_DATAOUT_0
5	SGPIO_DATAIN_0

Note: This pin-out is common with all other Romley EPSD products.

## 8. Front Panel Overview

### 8.1 Front Panel Features

The system includes a front panel that provides push button system controls and LED indicators for several system features. This section provides a description for the features.




Figure 39. Front Panel Options

Label	Description	Label	Description
A	Non-functional	F	System Status LED
B	Non-functional	G	Power Button w/Integrated LED
C	Non-functional	H	Non-functional
D	Non-functional	I	Non-functional
E	Non-functional	J	Non-functional

**F – System Status LED** – The System Status LED is a bi-color (Green/Amber) indicator that shows the current health of the server system. The system provides two locations for this feature; one is located on the Front Control Panel, and the other is located on the back edge of the server board that is viewable from the back of the system. Both LEDs are tied together and show the same state. The System Status LED states are driven by the on-board platform management subsystem. The following table provides a description of each supported LED state.

Table 23. System Status LED State Definitions

Color	State	Criticality	Description
Off	System is not operating	Not ready	System is powered off (AC and/or DC).
Green	Solid on	Ok	Indicates that the system status is “healthy”. The system is not exhibiting any errors. The AC power is present and the system is either in a standby state or has been powered on.
Amber	Solid on	SMBUS Alert Event Encountered	<ul style="list-style-type: none"> <li>▪ P12V is out of its limits.</li> <li>▪ P5V is out of its limits.</li> <li>▪ A fan fault has been detected.</li> <li>▪ An overtemperature event has been detected.</li> <li>▪ P3V3 is out of its limits.</li> <li>▪ Remote 1 and/or Remote 2 temperature sensor is either open or shorted.</li> </ul>

**G – Power Button** – Toggles the system power on and off. Pressing this button will send a signal to the integrated PDB board, which will either power on or power off the system. The integrated LED is a single color (Green) and can support different indicator states as defined in the following table.

Table 24. Power LED Functional States

State	Power Mode	LED	Description
Power-off	Non-ACPI	Off	System power is off.
Power-on	Non-ACPI	On	System power is on.

## ***Reference Documents***

Refer to the following documents for additional information:

- *Intel® Storage System JBOD 2000 Family Service Guide*