



Intel® RAID Controller SRCU42E

Tested Hardware and Operating System List

Revision 5.0

December, 2007

Enterprise Platforms and Services Division – Marketing

Revision History

Date	Revision Number	Modifications
10/30/04	1.0	Initial Release
06/30/05	2.0	Added firmware and driver update information
03/25/06	2.1	Update with latest Firmware and Test information
09/20/06	3.0	Update with latest Firmware and Test information
12/20/06	3.1	Update tested hard drive list
06/21/07	4.0	Update with latest Firmware and Test information
12/20/07	5.0	Update with latest Firmware and Test information

Disclaimers

THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION, OR SAMPLE.

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel retains the right to make changes to its test specifications at any time, without notice.

The hardware vendor remains solely responsible for the design, sale and functionality of its product, including any liability arising from product infringement or product warranty.

Copyright © Intel Corporation 2007. All rights reserved.

Intel, the Intel logo, and EtherExpress are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

*Other names or brands may be claimed as the property of others.

Table of Contents

1. Introduction	1
1.1 Test Overview.....	1
1.1.1 Basic Compatibility Testing.....	1
1.1.2 Adapter / Peripheral Compatibility and Stress Testing	2
1.2 Pass/Fail Test Criteria	3
2. Firmware Configurations.....	4
3. Operating Systems.....	5
3.1 Operating System Certifications	7
4. Intel® Server Boards.....	8
5. Enclosures, PCI Adapters, and Peripherals.....	10
5.1 External Storage	11
5.2 Internal Storage	11
5.3 CD-ROM Drives.....	12
5.4 Tape Drives	12
5.5 Hard Disk Controllers.....	12
5.6 SCSI RAID Controllers	12
5.7 Network Interface Controllers	13
6. Hard Disk Drives.....	15
6.1 Hard Disk Drives.....	15
7. Installation Guidelines	19
7.1 BIOS Console screen locks up if the option ROM is turned off for the slot the card is installed in	19

This page intentionally left blank

1. Introduction

This document is intended to provide users of the Intel® RAID Controller SRCU42E with a guide to the different operating systems, server boards, chassis, disk drives, and other peripherals tested by Intel for use with this RAID controller.

This document will be updated as additional testing is performed, or until the Intel® RAID Controller SRCU42E is no longer in production. Each new release of the document will include the information from previous releases. The latest version of this document is posted on the Internet.

Intel will only provide support for this RAID controller when it is installed in a system configured with the specified server boards, and when the server board is configured with the tested RAID firmware, system BIOS / firmware, and operating system versions.

Thorough testing has been performed on the RAID controller with Intel® server boards, Intel® drive enclosures, and the third party devices listed in this document. However, it is not practical to test the RAID controller in every possible combination of server board, drive enclosure, hard drive, and peripheral device. Sample combinations have been tested to gain confidence in their compatibility, and the devices listed were tested in one or more configuration.

1.1 Test Overview

Testing performed on the Intel® RAID Controller SRCU42E is classified under two categories:

- Compatibility Testing
- Stress Testing

1.1.1 Basic Compatibility Testing

Compatibility testing is performed with each supported operating system. Basic compatibility testing validates that the RAID controller can be used to install the operating system and that the base hardware feature set is functional. A small set of peripherals are used for installation purposes only. No additional add in cards are tested. Testing may include network connectivity and running proprietary and industry standard test suites.

Note: The latest version of an operating system signifies the latest supported version at the time of testing. New releases of this document may include a newly supported release of an operating system. Previous releases of a supported operating system may not be tested beyond the basic compatibility test process.

1.1.1.1 Support Commitment for Basic Installation Testing

Intel commits to provide the following level of customer support for operating systems that receive only basic installation testing:

- Intel will provide tested operating system drivers for each of the integrated controllers on the server board, as long as the controller vendor has a driver. Vendors are not required by Intel to develop drivers for operating systems that they do not already support. This may limit the functionality of certain server board integrated controllers.
- Intel will provide support to customers who experiences issues with the integrated controllers due to the installation or functionality of an operating if a driver is available.
- Intel does not provide support for issues related to the use of add-in adapters or peripheral installed in the server system with an operating system that received only basic installation testing.
- Support is defined as helping a customer to root cause an issue and determining an acceptable resolution to the operating system problem. The resolution may include, but is not limited to, onboard controller driver updates, engaging the vendor, BIOS changes, firmware changes, or determining an acceptable workaround for the issue with the customer.

1.1.2 Adapter / Peripheral Compatibility and Stress Testing

Adapter / Peripheral Compatibility and Stress testing is performed only on the most current release of a supported operating system at the time of testing. The Adapter / Peripheral Compatibility and Stress testing process consists of three areas:

- **Base Platform:** Each base platform will successfully install a given operating system, successfully run a disk stress test, and successfully run a network stress test.
- **Adapter Compatibility:** Adapter compatibility validation (CV) testing uses test suites to gain an accurate view of how the server performs with a wide variety of adapters under the primary supported operating systems. These tests are designed to show hardware compatibility between the cards and the server platform and include functional testing only. CV testing does not include heavy stressing of the systems or the cards.
- **Stress Testing:** This test sequence uses configurations with add-in adapters installed in all available slots (depending on chassis used), and runs for a minimum of 72-hours without injecting errors. Each configuration passes an installation test, a network/disk stress test, and tape backup test. Any fatal errors require a restart of the test.

1.1.2.1 Support Commitment for Adapter / Peripheral Compatibility and Stress Testing

Intel will provide the following level of customer support for operating systems that receive Adapter / Peripheral Compatibility and Stress testing:

- Intel will provide support to customers who experience issues with tested operating systems if they involve the installation or functionality of the server board with or without the adapters and peripherals listed in this document as having been tested under the operating system.
- Support is defined helping a customer to root cause an issue and determining an acceptable resolution to the problem. The resolution may include, but is not limited to, on-board controller driver updates, engaging the vendor, BIOS changes, firmware changes, or determining a workaround for the issue.
- Intel provides and test operating system drivers for each on-board video, network, and storage controller.
- Intel enables vendors to provide driver support for add-in adapters using these operating systems.
- Intel completes steps to achieve certification to ensure customers do not encounter problems. The actual certification is the responsibility of the customer.

Note: Intel does not provide a support commitment for operating systems, adapter cards, and peripherals not listed in this document. Intel will consider requests for support on a case-by-case basis.

1.2 Pass/Fail Test Criteria

For each operating system, adapter, and peripheral configuration, a test passes if specific criteria are met. Specific configurations with particular characteristics will be addressed individually. In general, a configuration passes testing if the following conditions are met:

- The operating system installed without error.
 - Manufacturer's installation instructions or Intel's best-known methods were used for the operating system installation.
 - No extraordinary workarounds were required during the operating system installation.
 - The server system behaved as expected during and after the operating system installation.
 - Application software installed and executed normally.
- Hardware compatibility tests ran to completion without error.
- Test software suites executed successfully:
 - Test and data files were created in the correct directories without error.
 - Files copied from the client to the server and back match the original without error.
 - Clients remain connected to the server system.
 - Industry standard test suites run to completion without error.

2. Firmware Configurations

The following table lists the controller and firmware configurations tested. This document will be updated with additional configurations as new revisions of the Intel® RAID Controller SRCU42E or firmware versions for that controller are released. Each configuration is assigned an identifier number that is referenced in the tables throughout this document.

Note: Intel will only provide support for adapters and peripherals in the configuration with which they were tested.

Base System Identifier #	Product Code	Part Number	Firmware Revision
1	SRCU42E	C77062-001	Ver. 514E
2	SRCU42E	C77062-002	Ver. 514J
3	SRCU42E		Ver. 514O
4	SRCU42E		Ver. 514P
5	SRCU42E		Ver. 514Q
6	SRCU42E		Ver. 514S

3. Operating Systems

The following table provides a list of supported operating systems for the Intel® RAID Controller SRCU42E. Each operating system was tested for compatibility with the Intel® RAID Controller SRCU42E configuration listed in Section 2. Operating systems are only supported in the specified base system configuration(s) they were tested with.

The following table also indicates whether each operating system received Basic Installation Testing or Adapter / Peripheral Compatibility and Stress Testing. See Section 1 for information on the support commitments for Basic Installation Testing and Adapter / Peripheral Compatibility and Stress Testing.

Any variations to the standard operating system installation process are documented in the Installation Guidelines section of this document. If there are no installation guidelines noted in the following table, then the operating system installed as expected using the manufacturer's installation instructions or Intel's best-known methods.

Note: *The operating systems listed below have been tested for compatibility with the Intel® RAID Controller SRCU42E but the operating system and its associated driver may not have been tested for compatibility with the server board you have selected. Refer to the supported operating system list for your server board to verify operating system compatibility with the server board. Only currently shipping operating system versions are tested with current firmware and driver versions. Older operating system versions may not have been tested with current firmware and drivers. For support of older operating system versions, you may need an earlier version of the RAID controller firmware and driver.*

Ident#	Operating System	Base System Configuration Tested and Type of Testing	Notes
1	Microsoft Windows 2003*	Configuration 1, 2, 3, 4, 5, 6 – Compatibility and Stress	
2	Microsoft Windows Server 2003 Small Business Server*	Configuration 1, 2 – Basic Installation	Application portion of the package was not tested and is not supported.
3	Microsoft Windows 2000 Advanced Server*, Service Pack 5	Configuration 1, 2, 3, 4 – Compatibility and Stress	
4	Microsoft Windows Small Business Server 2000*	Configuration 1, 2 - Basic Installation	Application portion of the package was not tested and is not supported.
5	Microsoft Windows XP*, SP2	Configuration 1, 2, 3, 4 – Compatibility and Stress	
6	Novell NetWare* 5.1, SP8	Configuration 1 – Basic Installation	
7	Novell NetWare* 6.0, SP5	Configuration 1 – Basic Installation	
8	Novell NetWare* 6.5, SP3	Configuration 1, 2, 3, 4 – Compatibility and Stress	
9	SCO* Open Server 5.0.7	Configuration 1, 2 – Basic Installation	
10	SCO* UnixWare 7.1.3	Configuration 1 – Compatibility and Stress	

Ident#	Operating System	Base System Configuration Tested and Type of Testing	Notes
11	SCO* UnixWare 7.1.4	Configuration 2 – Compatibility and Stress	
12	Red Hat* Enterprise Linux AS 3.0, U4	Configuration 1 – Compatibility and Stress	
13	Red Hat* Enterprise Linux AS 3.0, U5	Configuration 2 – Compatibility and Stress	
14	Red Hat* Enterprise Linux AS 4.0	Configuration 1, 2 – Compatibility and Stress	
15	SuSE* Linux Enterprise Server 9.0, SP1	Configuration 1, 2 – Compatibility and Stress	
16	SuSE* Linux Professional 9.1	Configuration 1, 2 – Basic Installation	
17	SuSE* Linux Professional 9.2	Configuration 1, 2 – Basic Installation	
18	Red Hat* Linux Professional 8.0	Configuration 1 – Basic Installation	
19	Red Hat* Linux Professional 9.0	Configuration 2 – Basic Installation	
20	SuSE* Linux Enterprise Server 8.0, SP3	Configuration 1 – Basic Installation	
21	SuSE* Linux Professional 9.0	Configuration 2 – Basic Installation	
22	Microsoft Windows 2003*, EM64T	Configuration 1, 2, 3, 4 – Compatibility and Stress	
23	Red Hat* Enterprise Linux AS 3.0, EM64T, U4	Configuration 1 – Compatibility and Stress	
24	Red Hat* Enterprise Linux AS 3.0, EM64T, U5	Configuration 2 – Basic Installation	
25	Red Hat* Enterprise Linux AS 4.0, EM64T	Configuration 2 – Compatibility and Stress	
26	SuSE* Linux Enterprise Server 9.0, EM64T SP1	Configuration 2 – Compatibility and Stress	
27	Microsoft Windows XP*, EM64T	Configuration 1, 2, 3, 4 – Basic Installation	
28	SuSE* Linux Enterprise Server 9.1, EM64T	Configuration 1, 2 – Basic Installation	
29	Red Hat* Enterprise Linux AS 3.0, EM64T, U6	Configuration 3 – Compatibility and Stress	
30	Red Hat* Enterprise Linux AS 4.0, EM64T, U1	Configuration 3 – Compatibility and Stress	
31	Red Hat* Enterprise Linux AS 4.0, EM64T, U2	Configuration 3, 4 – Compatibility and Stress	
32	SuSE* Linux Enterprise Server 9.0, SP2	Configuration 3, 4 – Compatibility and Stress	
33	SuSE* Linux Enterprise Server 9.0, EM64T SP2	Configuration 3, 4 – Compatibility and Stress	
34	SuSE* Linux Enterprise Server 9.0, SP3	Configuration 3, 4 – Compatibility and Stress	
35	SuSE* Linux Enterprise Server 9.0, EM64T SP3	Configuration 3, 4 – Compatibility and Stress	

3.1 Operating System Certifications

Listed below are the operating systems that Intel will certify with the Intel® RAID Controller SRCU42E. Each customer is responsible for their own certification from the individual operating system vendors. In many cases, customers may leverage their operating system certifications from the testing completed by Intel. See the “Comments” column next to each operating system in the table below for additional information. Intel’s certifications, pre-certification, and operating system testing may help reduce some of the risk in achieving customer certifications with the operating system vendors.

Operating System	Certification Listing	Comment
Microsoft Windows 2003 Enterprise Server*	SRCU42E	OEM must request certification by Microsoft or their specific product. Search on SRCU42E http://www.microsoft.com/hwdq/hcl/search.asp http://developer.intel.com/design/servers/whql.htm
Microsoft Windows 2000 Advanced Server*	SRCU42E	OEM must request certification by Microsoft for their specific product. Search on SRCU42E http://www.microsoft.com/hwdq/hcl/search.asp http://developer.intel.com/design/servers/whql.htm
Novell NetWare* 5.1 and 6.0, 6.5	SRCU42E	Novell checks Intel’s test results, certifies (if appropriate), and posts the certificate on their web site. The customer can leverage the Intel certification if the customer product meets the operating system vendor standard. http://developer.novell.com/yes

4. Intel® Server Boards

This list includes the Intel® Server Board software versions with which the server boards were configured at the time of testing.

Intel® Server Board	Microsoft Windows 2003*	Microsoft Small Business Server 2003*	Microsoft Windows 2000*	Microsoft Small Business Server 2000*	Microsoft Windows XP*	Red Hat* Linux v8.0	Red Hat* Linux v9.0	Red Hat* Linux AS2.1	Red Hat* Linux AS3.0	Novell NetWare* v6.5	SuSE* Linux ES 9.0 SP3	SuSE* Professional9.0	SCO Open Server* 5.0.7	SCO UnixWare* 7.1.3	Microsoft Windows 2003* x64	Microsoft Windows XP* x64	Red Hat* Linux ES4.0 U2 x86_64	SuSE* Linux ES 9.0 SP3 x86_64
SE7520BD2 BIOS BMC FRU/SDR HSC P3.1 N/A 6.4.1 1.12	X	X	X	X	X		X	X	X	X	X	X		X	X		X	X
SE7520AF2 BIOS BMC FRU/SDR HSC P02 N/A 6.4.1 1.12	X	X	X	X	X		X	X	X	X	X	X		X	X		X	X
SE7320SP2 BIOS BMC FRU/SDR HSC P05 2.40 1.20 1.12	X	X	X	X	X		X	X	X	X	X	X		X	X		X	X
SR7520JR2 BIOS BMC FRU/SDR HSC P10 2.40 6.2.1 1.08	X	X	X	X	X		X	X	X	X	X	X		X	X		X	X
SE7320VP2 BIOS BMC FRU/SDR HSC P02 N/A 6.2.1 N/A	X	X	X	X	X		X	X	X	X	X	X		X	X		X	X
SE7221BK1-E BIOS BMC FRU/SDR HSC P02 N/A 6.2.1 N/A	X	X	X		X	X	X	X	X	X	X				X		X	X
SE7221BA1-E BIOS BMC FRU/SDR HSC P0155 N/A N/A N/A	X		X						X						X			
SE7320EP2 BIOS BMC FRU/SDR HSC P01 N/A N/A N/A	X		X		X				X	X		X			X	X		

Intel® Server Board	Microsoft Windows 2003*	Microsoft Small Business Server 2003*	Microsoft Windows 2000*	Microsoft Small Business Server 2000*	Microsoft Windows XP*	Red Hat* Linux v8.0	Red Hat* Linux v9.0	Red Hat* Linux AS2.1	Red Hat* Linux AS3.0	Novell NetWare* v6.5	SuSE* Linux ES 9.0 SP3	SuSE* Professional9.0	SCO Open Server* 5.0.7	SCO UnixWare* 7.1.3	Microsoft Windows 2003* x64	Microsoft Windows XP* x64	Red Hat* Linux ES4.0 U2 x86_64	SuSE* Linux ES 9.0 SP3 x86_64
SE7525RP2 BIOS BMC FRU/SDR HSC P01 N/A N/A N/A	X		X		X				X	X		X			X	X		
SE8500HW4 BIOS BMC FRU/SDR HSC P04 34 24 1.06	X		X		X				X	X	X				X		X	X
SE7230NH1-E BIOS BMC FRU/SDR HSC 0497P N/A N/A N/A	X														X		X	
S3000AH BIOS BMC FRU/SDR HSC R28 N/A N/A N/A	X										X				X		X	X
S5000VSA BIOS BMC FRU/SDR HSC R070 56 41 2.05	X														X		X	
S5000PAL/XAL BIOS BMC FRU/SDR HSC R070 56 41 2.05	X		X		X					X	X				X	X	X	X
S5000PSL / XSL / XVN BIOS BMC FRU/SDR HSC R070 56 41 2.05	X		X		X					X	X				X	X	X	X
SC5000RA BIOS BMC FRU/SDR HSC R057 50 35 N/A	X		X		X					X	X				X	X	X	X
S3200SH / S3210SH BIOS BMC FRU/SDR HSC R33 N/A N/A N/A	X														X			

5. Enclosures, PCI Adapters, and Peripherals

Testing of enclosures, add-in cards, and peripherals was performed on the Intel® RAID Controller SRCU42E by Intel labs, independent test labs, or the vendor. Compatibility and stress testing was performed with the latest version of an operating system available at the time of testing.

Although a large sample of configurations were tested, not all devices were tested under all operating systems, and not all possible combinations or configurations of third-party devices were tested for inter-compatibility due to the large number of possible configurations. Refer to the Tested Hardware and Operating System List for the server board to verify compatibility.

Add-in adapter card and peripheral compatibility and stress testing is performed with the latest version of an operating system at the time the validation testing occurred. The following table shows the operating system and base system configurations used to validate each device. The adapters are divided into categories based on their functionality. All integrated onboard devices are tested by default and are therefore not included in the following tables.

Note: *Not all adapter cards and peripherals were tested under all operating systems.*

Any variations to the standard adapter installation process or to expected adapter functionality are documented in the Installation Guidelines section of this document. If there are installation guidelines affecting a particular adapter and operating system combination, these are referenced in the following table. If there are no installation guidelines noted in the following table, then the adapter installed and functioned as expected using manufacturer's installation instructions or Intel's best-known methods.

Note: *Adapter cards are normally tested with unused add-in adapters and onboard controller expansion ROMs disabled in BIOS Setup. Intel recommends that customers disable the option ROM for add-in controllers and/or the onboard controllers when not booting from the controller or needing to use its built-in utilities.*

5.1 External Storage

Note: Enclosures are listed only if they were attached to the Intel® RAID Controller SRCU42E.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Dell	PowerVault* 201S		Ultra160		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Dell	PowerVault* 211S		Ultra160		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Dell	PowerVault* 220S		Ultra320	Tested with Microsoft Cluster Server*	1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
StorCase	S10A155		Ultra320		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
StorCase	S10A172		Ultra320	Tested with Microsoft Cluster Server*	1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22

5.2 Internal Storage

Note: Enclosures are listed only if they were attached to the Intel® RAID Controller SRCU42E during testing.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Intel	Intel® Server Chassis SC5300		Ultra320/ SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® Server Chassis SC5250-E		Ultra320/ SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® Server Chassis SC5275-E		Ultra320/ SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® Server Chassis SR1400		Ultra320/ SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® Server Chassis SR1450		Ultra320/ SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® Server Chassis SR2400		Ultra320/ SCA		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22

5.3 CD-ROM Drives

Note: CD-ROM drives are listed only if the operating system was installed from this device.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Sony	CDU5211	CDU5211	IDE		1, 3, 6, 7, 8, 9, 10
Panasonic	AXXDVDFloppy	SR-8177-B	IDE		1, 3, 6, 7, 8, 9, 10

5.4 Tape Drives

Note: Tape drives are listed ONLY if they were attached to the RAID Controller SRCU42E.

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Sony	SDX-500	SDX-500C/TB	Ultra2/wide		1, 3, 6, 9
Sony	PCBacker II	SDT-11000/PB	Ultra2/wide		1, 3, 6, 7, 8, 9, 10
Seagate	SCORPION* 40		SCSI DDS4 DAT		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Quantum	DLT8000				1, 3, 6, 9
Sony	SDT 9000				3, 5, 6, 8, 10
Seagate	SCORPION* 24	STD2401LW	DDS4 DAT		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28

5.5 Hard Disk Controllers

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Adaptec	ASC-39320	ASC-39320	PCI-X 133		1, 3, 6, 7, 8, 9, 10
Adaptec	ASC-39160	ASC-39160	PCI 64/66		3, 5, 6, 8, 10
Emulex	LightPulse LP9402	LP9402	FC-HBA PCI 64/66		1, 3, 6, 7, 8, 9, 10
LSI Logic	LSI20160	LSI20160	PCI 64/66		1, 3, 6, 9
LSI Logic	LSI20160L	LSI20160L	PCI 64/66		1, 3, 6, 9
QLogic	QLA2200L	QLA2200L	PCI 64/66		1, 3, 6, 7, 8, 9, 10

5.6 SCSI RAID Controllers

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Adaptec	SCSI RAID 2120S	ASR-2120S	PCI 64/66		3, 5, 6, 8, 10
Adaptec	SCSI RAID 2200S	ASR- 2200S/64MB	PCI 64/66		1, 3, 6, 9
Adaptec	SCSI RAID 3410S	ASR-3410S	PCI 64/66		1, 3, 6, 9
ICP-Vortex	GDT4523RZ	GDT4523RZ	PCI 32/66		3, 5, 6, 8, 10
ICP-Vortex	GDT6523RS	GDT6523RS	PCI-32/33		3, 5, 6, 8, 10

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
ICP-Vortex	GDT8623RZ	GDT8623RZ	PCI 64/66		1, 3, 6, 9, 11
ICP-Vortex	GDT8663RZ	GDT8663RZ	PCI 64/66		1, 3, 6, 9, 11
Intel	Intel® RAID Controller SRCU31L	SRCU31LA	PCI-32/33		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® RAID Controller SRCU31	SRCU31A	PCI 64/33		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® RAID Controller SRCZCR	SRCZCR	PCI 64/66		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® RAID Controller SRCU32	SRCU32U	PCI 64/66		1, 3, 6, 9, 11, 15, 16, 17, 18, 19, 20
Intel	Intel® RAID Controller SRCU42L	SRCS42L	PCI 64/66		1, 3, 5, 7, 11, 15, 16, 17, 18, 19, 20, 21, 22
Intel	Intel® RAID Controller SRCS16	SRCS16	PCI 64/66		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel	Intel® RAID Controller SRCS28X	SRCS28X	PCI-X*		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel	Intel® RAID Controller SRCZCRX	SRCZCRX	PCI-X*		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel	Intel® RAID Controller SRCU41L	SRCU41L	PCI 64/66		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel	Intel® RAID Controller SRCU42X	SRCU42X	PCI-X*		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28

5.7 Network Interface Controllers

Manufacturer	Model Name	Model Number	Interface	Comment	Operating System Identifier
Intel	Intel® PRO/100+ S Server Adapter	PILA8470D3G1P20	PCI-32/33		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel	Intel® PRO/100 S Server	PILA8470D3G1L	PCI-32/33		3, 5, 6, 8, 10
Intel	Intel® PRO/100 S Dual Port Server adapter	PILA8472D3G1P	PCI 64/33		1, 3, 6, 9
Intel	Intel® PRO/1000XT Gigabit Server Adapter	PILA8490XTP20	PCI-X* 133		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Intel	Intel® PRO/1000T Server Adapter	PWLA8490T	PCI 64/66		1, 3, 6, 9

Intel	Intel® PRO/1000 XT Server Adapter	PWLA8490XT	PCI-X* 133		3, 5, 6, 8, 10
Intel	Intel® PRO/1000 XT Server Adapter	PWLA8490XTL	PCI-X* 133		3, 5, 6, 8, 10
Intel	Intel® PRO/1000 MF Server Adapter	PWLA8492MF	PCI-X* 133		1, 3, 6, 9
Intel	Intel® PRO/1000MT Dual Port Server Adapter	PWLA8492MT	PCI-X* 133		1, 3, 5, 7, 8, 9, 11, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28

6. Hard Disk Drives

Enclosure, add-in card, and peripheral testing was performed on the Intel® RAID Controller SRCU42E by Intel labs, independent test labs, or by the vendor. The Intel® RAID Controller SRCU42E compatibility and stress testing is performed with the latest version of an operating system available at the time of testing. Although a large sample of configurations were tested, not all devices were tested under all operating systems, and not all possible combinations or configurations of third-party devices were tested for inter-compatibility due to the large number of possible configurations. Refer to the Tested Hardware and Operating System List for the server board to verify compatibility.

Add-in adapter card and peripheral compatibility and stress testing will only be performed with the latest version of an operating system available at the time of testing. The following table shows the operating system and base system configurations used to validate each device. The adapters are divided into categories based on their functionality. All integrated onboard devices are tested by default and are therefore not included in the following tables.

Note: *Not all adapter cards and peripherals were tested under all operating systems.*

Any variations to the standard adapter installation process or to the expected adapter functionality are documented in the Installation Guidelines section of this document. If there are installation guidelines affecting a particular adapter and operating system combination, these are referenced in the following table. If there are no installation guidelines noted in the following table, then the adapter installed and functioned as expected using manufacturer's installation instructions or Intel's best-known methods.

Note: *Adapters cards are normally tested with unused add-in adapters and onboard controller expansion ROMs disabled in BIOS Setup. Intel recommends that customers disable the option ROM for add-in controllers and the onboard controllers when not booting from the controller or using its built-in utilities.*

6.1 Hard Disk Drives

Note: *Hard disk drives are listed only if they were attached to the Intel® RAID Controller SRCU42E during testing.*

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size	Tested Operating Systems
Fujitsu		MAP3147NC	Ultra320	10 K	147 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu	Allegro 5	MAG3182LC	Ultra160/SCA	10 K	18 GB	1, 3, 6, 9
Fujitsu	Allegro 7LX	MAM3184MC	Ultra160/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10
Fujitsu		MAS3184NC	Ultra320	15 K	18 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu	Allegro 7 LE	MAN3367MC	Ultra160/SCA	10 K	37 GB	1, 3, 6, 7, 8, 9, 10
Fujitsu		MAP3367NC	Ultra320	10 K	37 GB	1, 3, 5, 7, 18, 19, 21, 22, 23, 24, 25, 26, 27, 28

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size	Tested Operating Systems
Fujitsu		MAS3367NC	Ultra320	15 K	37 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu		MAP3735NC	Ultra320	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu		MAS3735NC	Ultra320	15 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
Fujitsu	Allegro 5 LE	MAE3091LC	Ultra160/SCA	15 K	9 GB	3, 5, 6, 8, 10
Hitachi	Ultrastar*10K300	HUS103030FL3800	Ultra320/SCA	10 K	300 GB	1, 3, 5, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30
Hitachi	Ultrastar*10K300	HUS103014FL3800	Ultra320/SCA	10 K	147 GB	1, 3, 5, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 30, 31
Hitachi	Ultrastar*10K300	HUS103073FL3800	Ultra320/SCA	10 K	73 GB	1, 3, 5, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30
Hitachi	Ultrastar*15K147	HUS151414FL3800	Ultra320/SCA	15 K	147 GB	1, 3, 5, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 30, 31
Hitachi	Ultrastar*15K147	HUS151473FL3800	Ultra320/SCA	15 K	73 GB	1, 3, 5, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 30, 31
Hitachi	Ultrastar*15K147	HUS151436FL3800	Ultra320/SCA	15 K	36 GB	1, 3, 5, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 25, 27, 28, 29, 30
Hitachi	Ultrastar*146Z10	IC35L146UCDY10-0,	Ultra320/SCA	10 K	146 GB	1, 3, 5, 7, 18, 19, 21, 22, 23, 24, 25, 26, 27, 28
Hitachi	Ultrastar*146Z10	IC35L018UCDY10-0	Ultra320/SCA	10 K	18 GB	1, 3, 5, 7, 18, 19, 21, 22
Hitachi	Ultrastar*146Z10	IC35L036UCDY10-0	Ultra320/SCA	10 K	36 GB	1, 3, 5, 7, 18, 19, 21, 22
Hitachi	Ultrastar*146Z10	IC35L073UCDY10-0	Ultra320/SCA	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
IBM	UltraStar 146ZN	IC35L146UCDY10-0	Ultra320/SCA	10 K	146 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 22, 23, 24, 25, 26, 27, 28
IBM	UltraStar 36Z15	IC35L018UCPR15	Ultra160/SCA	15 K	18 GB	3, 5, 6, 8, 10
IBM	UltraStar 73LZX	IC35L036UCD210	Ultra160/SCA	10 K	36 GB	1, 3, 6, 9
Maxtor	Atlas 10K IV	8B146L0	Ultra320/SCA	10 K	146 GB	1, 3, 5, 7, 18, 19, 21, 22, 23, 24, 25, 26, 27, 28
Maxtor	Atlas 10K IV	8B146J0	Ultra320/SCA	10 K	146 GB	1, 3, 5, 7, 18, 19, 21, 22
Maxtor	Atlas 10K III-Ultra320	KU18J017	Ultra320/SCA	10 K	18 GB	1, 3, 6, 9
Maxtor	Atlas 10K III-Ultra320	KU18J07E	Ultra320/SCA	10 K	18 GB	3, 5, 6, 8, 10
Maxtor	Atlas 10K IV	8B036L0	Ultra320	10 K	36 GB	1, 3, 5, 7, 18, 19, 21, 22

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size	Tested Operating Systems
Maxtor	Atlas 10K IV	8B036J0	Ultra320/SCA	10 K	36 GB	1, 3, 5, 7, 18, 19, 21, 22, 23, 24, 25, 26, 27, 28
Maxtor	Atlas 10K III-Ultra320	KU73J017	Ultra320/SCA	10 K	73 GB	1, 3, 6, 9
Maxtor*	Atlas 10K IV	8B073L0	Ultra320	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22
Maxtor	Atlas 10K IV	8B073J0	Ultra320/SCA	10 K	73 GB	1, 3, 5, 7, 18, 19, 21, 22, 23, 24, 25, 26, 27, 28
Quantum	Atlas 10K III	KW18J014	Ultra320/SCA	10 K	18 GB	3, 5, 6, 8, 10
Quantum	Atlas 10K III	KW36J011	Ultra160/SCA	10 K	36 GB	1, 3, 6, 9
Quantum	Atlas IV	KN09J011	Ultra160/SCA	7.2 K	9 GB	1, 3, 6, 7, 8, 9, 10
Quantum	Atlas IV	KN09L011	Ultra160/Wide	7.2 K	9 GB	1, 3, 6, 7, 8, 9, 10
Seagate	Cheetah* 73	ST173404LC	Ultra160/SCA	10 K	73 GB	3, 5, 6, 8, 10
Seagate	Cheetah* 36ES	ST318406LC	Ultra160/SCA	10 K	18 GB	1, 3, 6, 7, 8, 9, 10
Seagate	Cheetah* X15	ST318451LC	Ultra160/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10
Seagate	Cheetah* X15	ST318432LC	Ultra320/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10
Seagate	Cheetah* X15	ST318452LC	Ultra160/SCA	15 K	18 GB	1, 3, 6, 9
Seagate	Cheetah* 15K.3	ST318453LC	Ultra320/SCA	15 K	18 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17
Seagate	Cheetah* 73LP	ST336605LC	Ultra160/SCA	10 K	36 GB	1, 3, 6, 9
Seagate	Cheetah* 10K.6	ST336607LC	Ultra320/SCA	10 K	36 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Seagate		ST336732LC	Ultra320/SCA	15 K	36 GB	1, 3, 5, 7, 11, 15, 16, 177, 18, 19, 21, 21, 22
Seagate		ST336432LC	Ultra320/SCA	15 K	36 GB	1, 3, 5, 7, 11, 15, 16, 177, 18, 19, 21, 21, 22
Seagate	Cheetah* 15K.3	ST373453LC	Ultra320/SCA	15 K	73 GB	1, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28
Seagate	Barracuda* 18XL	ST39236LC	Ultra160/SCA	7.2 K	9 GB	1, 3, 6, 9
Seagate	Cheetah* 18XL	ST39204LC	Ultra160/SCA	10 K	9 GB	1, 3, 6, 7, 8, 9, 10
Seagate	Barracuda* 18XL	ST39236LC	Ultra160/SCA	7.2 K	9 GB	1, 3, 6, 9
Seagate	10K7	ST3300007LC	Ultra320/SCA	10 K	300 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35
Seagate	10K7	ST3146707LC	Ultra320/SCA	10 K	146 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35
Seagate	10K7	ST373207LC	Ultra320/SCA	10 K	73 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35
Seagate*	15K4	ST3146854LC	Ultra320/SCA	15 K	146 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35
Seagate*	15K4	ST373454LC	Ultra320/SCA	15 K	73 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35

Manufacturer	Model Name	Model Number	Interface	RPM	Drive Size	Tested Operating Systems
Seagate*	15K4	ST336754LC	Ultra320/SCA	15 K	36 GB	1, 3, 5, 8, 22, 27, 31, 32, 33, 34, 35

7. Installation Guidelines

7.1 BIOS Console screen locks up if the option ROM is turned off for the slot the card is installed in

Issue: When the option ROM installed card slot is turned off, the system will hang if the RAID controller is access through the RAID BIOS console.

Implication: The system will hang when accessing the controller in RAID BIOS Console if the slot the option ROM is in is turned off.

Guideline: You must turn on the option ROM for the RAID controller in the BIOS Setup Utility before you activate the RAID BIOS Console by typing 'Ctrl+G'.

Status: No available workaround.